

Advantech AE Technical Share Document

| | | | |
|-----------------|--|------------|---------------|
| Date | 2015 / 03 / 31 | SR# | 1-2040302635 |
| Category | ■ FAQ □ SOP | Related OS | WinCE5, Win32 |
| Abstract | Easy troubleshooting for APAX IO modules | | |
| Keyword | Troubleshooting, APAX IO, LED status | | |
| Related Product | APAX IO module series | | |

[Problem]

How to use the LED indicator on APAX IO module to analyze the module status and do the troubleshooting?



LED Indicator & troubleshooting

[Solution]

Case 1: LED always **bright**

Causation: I/O modules are in the normal condition and without any problems.

LED – green color: APAX IO ID number is in the 0~15 section.



LED – orange color: APAX IO ID number is in the 16~31 section.




Case 2: LED continues **flashing one time every 2 seconds**

Causation: I/O module has problem itself

Solution:

- Download the latest firmware again to see if it works well
- If problem still exists after updating firmware, need further support




Case 3: LED continues **flashing 2 times every 2 seconds**

Causation: I/O module has communication problem

Solution:

- Check if the controller or coupler is installed and power-on
- Check if the Ethernet connection is broken when you have remote expansion
- Check if any backplane is broken
- Download latest firmware again to see if it works well
- If problem still exists after updating firmware, need further support



Case 4: LED continues **flashing 4 times every 2 seconds**

Causation: ID number of one I/O module conflicts with another I/O module

Solution:

- Check ID number of all I/O modules in the same system
- Adjust the ID number to avoid different I/O modules with the same ID number. Then reboot the system and it should work fine
- If the LED continues flashing after you have adjusted the ID number, need further support

