

# **Advantech AE Technical Share Document**

Date	2020/8/3	Release Note	□Internal <b>■</b> External
Category	■ FAQ □ SOP	Related OS	WIN10
Abstract	Intel® 82579V Gigabit Ethernet PHY has a Yellow Exclamation Mark and		
	Changes to 82579LM		
Keyword	82579V, 82579LM, WIN10.		
Related Product	The Platforms which use 82579V with WIN10.		

#### Problem Description:

When it comes out of sleep, hibernate or fast startup in WIN10, the adapter 82579V shows as Intel 82579LM and has a yellow exclamation. At the same time, the connection is disconnected



### **■** Problem Analysis:

The problem occurs when the Intel® 82579V Gigabit Ethernet PHY network connection incorrectly reports the device ID as an Intel® 82579LM Gigabit Ethernet Controller network connection during operation, resulting in a Windows \* Code 10 error and loss of network connectivity.




### Brief Solution:


#### Method 1:

### Turn off sleep

- A. Click the magnifying glass icon in the bottom-left corner of your screen.
- B. Then type power & sleep into the search bar and click Open.




C. Finally, click the drop-down box under Sleep and change it to Never.






#### Turn off hibernation

- A. Click the magnifying glass icon in the bottom-left corner of your screen. This is next to the Windows 10 logo.
- B. Then type Command Prompt into the search bar.
- C. Next, click Run as administrator.




- D. Then type powercfg.exe /hibernate off into the Command Prompt.
- E. Finally, hit Enter on your keyboard. This will disable the hibernation mode on your computer.






### Turn off fast startup

A. Open "Control Panel" and click "Power Option", and follow below picture.



B. Click "Choose what the power buttons do"






C. Click "Change settings that are currently unavailable"



### D. Disable "Turn on fast startup"





#### Method 2:

## **Update the NVRAM**

- A. Download the utility from the Intel download center https://downloadcenter.intel.com/download/29615?v=t
- B. Select the correct tool file name based on the operating system installed (Take DOS as example)
  - a. 32-bit Windows use the utility in the **Win32** directory.
  - b. b. 64-bit Windows use the utility in the **Win64e** directory.
  - c. DOS use the utility in the **DOS** directory.
- C. Run the executable file from the common prompt
- D. The NVM image will be updated. Reboot the computer for best results.

#### Reference:

- 1. NVRAM update utility: <a href="https://downloadcenter.intel.com/download/29615?v=t">https://downloadcenter.intel.com/download/29615?v=t</a>
- 2. Microsoft(turn off fast startup): <a href="https://answers.microsoft.com/en-us/windows/forum/windows">https://answers.microsoft.com/en-us/windows/forum/windows</a> 10-update/turn-off-fast-startup/5362cd29-86ca-4b39-be60-718446f9d5f8

#### **■** Contact Window and File Link:

If you have any questions, please contact Dennis89.Huang #1241 You can download this file on Global AE SharePoint - FAQ