

## Using Macro Command to Disable Communication Link

The macro command EN\_LINK can enable or disable a communication link dynamically. The format and the parameters of this command are shown below.

EN\_LINK(*p1*, *p2*, *p3*)

*p1*: The link number of the communication link to be enabled or disabled.

*p2*: The node address of the sub-link to be enabled or disabled. If the specified link has no sub-link, this parameter is ignored. If the specified link has sub-links and you want to enable or disable the link itself, this parameter should be 0.

*p3*: Specifies whether to enable or disable the specified link/sub-link. If this parameter is 0, the link/sub-link is disabled. If the parameter is 1, the link/sub-link is enabled.