

## Advantech AE Technical Share Document


<b>Date</b>	2017 / 05 / 23	<b>Release Note</b>	<input type="checkbox"/> Internal <input checked="" type="checkbox"/> External
<b>Category</b>	<input checked="" type="checkbox"/> FAQ <input type="checkbox"/> SOP	<b>Related OS</b>	Windows7/8/10
<b>Abstract</b>	How to reset the home key back to default setting in GLtool bar		
<b>Keyword</b>	Reset , home key , GLtool bar		
<b>Related Product</b>	TPC-1840WP,TPC-2140WP,TPC-1881WP,TPC-1581WP,SPC-1840WP,SPC-2140WP,SPC-1881WP		

### ■ **Problem Description:**

How to reset the home key back to default setting in GLtool bar

### ■ **Brief Solution - Step by Step:**

1. Long press the "Home key setting" instead of Home Key, then you may need to key the password again. Just like when you set the new function for Home key.
2. Then you will see a "x" on the home key, click it.



### ■ **Problem Analysis:**

### ■ **Reference:**

### ■ **Contact Window and File Link:**

If you have any questions, please contact John.Chuang #7707

You can download this file on [Global AE SharePoint - FAQ](#)