

Advantech AE Technical Share Document

Date	2018 / 04 / 16	Release Note	□ Internal ■ External
Category	■ FAQ □ SOP	Related OS	Windows 10
Abstract	AIM-37 Barcode Scanner Can't Work after Un-dock AIM-P701.		
Keyword	AIM-37, Barcode Sacnner, AIM-P701.		
Related Product	AIM-37, AIM-P701.		

Problem Description:


AIM-37 barcode scanner can't work after un-dock AIM-P701.

Problem Analysis:

The barcode scanner of AIM-37 adopts <u>USB Port</u>, which can be directly used without any driver. Nonetheless, if just un-dock AIM-37 from AIM-P701, <u>USB Port of barcode scanner</u> may be interfered by it.

The problem can be analyzed from **Ports (COM & LPT)** in **Device Manager**:


1. Before dock AIM-37 at AIM-P701, there is an <u>internal COM Port</u> in AIM-37 initionally (the <u>internal COM Port</u> in the example is <u>COM1</u>).



Written by Gene.Lo 1



2. After dock AIM-37 at AIM-P701, <u>Device Manager</u> will automatically refresh and show up <u>other COM Ports</u> from AIM-P701.



3. When un-dock AIM-37 from AIM-P701, <u>Device Manager</u> should automatically refresh to make <u>Ports(COM & LPT)</u> remain only <u>internal COM Port (COM1)</u> as initional status.

However, if <u>Device Manager</u> doesn't automatically refresh and still remain <u>other COM</u> <u>Ports</u> from AIM-P701, AIM-37 may confuse to detect devices, and also make <u>USB Port of barcode scanner</u> not work.

Written by Gene.Lo 2



■ Brief Solution - Step by Step:

1. Press refresh icon to refresh Device manager.




2. If it still can't work, dock AIM-37 at AIM-P701 and un-dock again, in order to make <u>Device</u> <u>manager</u> automatically refresh and detect <u>USB Port of barcode scanner</u> one more time.

% Note

➤ When undock AIM-37 from AIM-P701, in order to protect its **Ground Pin**, it is recommend to un-dock straight up and down, instead of rotating.



When use AIM-37 to scan barcodes, ensure that the red spot from barcode scanner aims to scanned barcodes.



Contact Window and File Link:

If you have any questions, please contact Gene.Lo #7187 You can download this file on Global AE SharePoint - SOP

Written by Gene.Lo 3