

Advantech AE Technical Share Document

Date	2018 / 05 / 28	SR#	1-3972266450
Category	■FAQ□SOP	Related OS	N/A
Abstract	[Notification] UNO-2473G-J doesn't have the terminal resistor switch for adjusting		
Keyword	Terminal resistor, UNO-2473G-J		
Related Product	UNO-2473G-J		

■ Problem Description:

Correct the User Manual information: Only **UNO-2473-E3AE** has the SW1 to adjust terminal function
UNO-2473G-J COM 3 & COM 4 don't have the switch to adjust. The default RS-485 terminal resistor is enabled.




Figure A.2 UNO-2473G Connector & Jumper Locations (front)

A.3 Connectors and Jumpers

Table A.3: Connectors and Jumpers	
Label	Function
CN14 CN15	PCI Express Mini Card Socket
CN5	USB Pin Headers
BH1	Battery for RTC
CN29	ON/OFF/RESET Switch
CN11	COM3, COM4
SW1	Turn On/Off Termination Resistors for COM3/COM4
SW4	No Function