

Advantech AE Technical Share Document

| | | | |
|-----------------|----------------------------------------------------------------------|------------|------------------------------|
| Date | 2015 / 10 / 16 | SR# | 1-2271830532 |
| Category | <input type="checkbox"/> FAQ <input checked="" type="checkbox"/> SOP | Related OS | Microsoft Windows XP / 7 / 8 |
| Abstract | How to use thermocouple measurement with USB-4718 correctly? | | |
| Keyword | DAQNavi Driver, Legacy DAQ Driver, USB-4718, USB module | | |
| Related Product | USB-4718 | | |

■ **Problem Description:**

This document describes how to use thermocouple measurement with USB-4718 correctly.

How to set different type of thermocouple by using DAQNavi utility.

■ **Brief Solution :**

After user get USB-4718 module at first time, please check there is a CJC device on USB-4718.

Please refer Figure 1., and do not take it off when it use for thermocouple measurement, otherwise the result value won't be correct by CJC device.




Figure 1. USB-4718 with CJC device

Then user can set different type through DAQNav, as Figure2.

Please select USB-4718 -> Device Setting -> Channels Connection Type -> Set Value Range




Figure 2. Set thermocouple type by using DAQNav

■ Reference: