


POC-W212 Appearance



Front-view

Rear-view

* Please use VESA compatible mounting only.



Packing List


- (1) POC-W212 x 1
- (2) Accessory box x 1
 - ✓ This quick start manual x 1
 - ✓ Simpro HPU101-107 (18Vdc/5.55A) adapter x 1
 - ✓ Drivers & Manual CD x 1
 - ✓ Tool bag x 1: spare screws x 4, rubber connectors x 13, and DRAM thermal pad x 1.
 - ✓ Mylar x 1: for USB bracket fixture

(1) Function Keys



- (1) Power On/Off
- (2) Volume Control
- (3) Touchscreen Function Control
- (4) Read Light Control
- (5) Brightness Control


(2) I/O Ports



- (1) PCIe(x4) Card Slot
- (2) Power DC-IN
- (3) 2 x USB 2.0 Ports & 2 x USB 3.0 Ports
- (4) VGA Port
- (5) HDMI-out Port
- (6) 2 x Gigabit Ethernet (isolated) Interfaces (RJ-45)
- (7) 1 x RS-232 (isolated) & 1 x RS-232/422/485 (isolated) Serial Port
- (8) Equipotential Terminal Pin

How to setup IP54 wiring:


- 1) Remove plugs with a pair of tweezers and take off exterior I/O cover.



- 2) Insert appropriate rubber connectors into appropriate slots and place cables in holes.



Suggestion of suitable hole sizes for your reference:




- D. $\Phi 4$ for USB cable (2pcs)
- E. $\Phi 5$ for LAN or COM cable (1pc)
- F. $\Phi 6$ for Power or HDMI cable (1pc)

- 3) Reinstall I/O exterior and plugs.

Notice of Plugs:

- 1) Use tweezers to pull out/insert back plugs when detaching back cover to change hardware configuration.
- 2) Read number on plugs for mapping:



Plugs:



(3) Easy Setup

Power On Computer:

- 1) Make sure Equipotential Terminal is connected to equipotential ground in the hospital.
- 2) Connect the adapter to Power DC-IN. Please note that using different adaptors may put the system into risk.
- 3) Press Power On/ Off. The button will turn green.

Driver Installation:

Advantech supports "one key" driver installation. A user can simply double click an icon to install all the drivers.

- 1) Make sure the OS has been successfully installed. If you have difficulty installing an OS, please follow the instructions in the POC-W212 User Manual.
- 2) Download the "one key" package from the Advantech Support website:
http://support.advantech.com/support/new_default.aspx.
Open the folder and double click "InstallAll.exe."
- 3) An Install dialog will appear. Follow the instructions shown in the dialog to finish the installation.

* Please use a clean OS to install this auto installation; otherwise, unexpected errors may occur.
* Should you only want to install specific drivers, please follow the instructions in the POC-W212 User Manual.

Notice:

- PCIe connection requires matching of specification. Not every PCIe card assures compatibility. Contact Advantech regional service center before use

(4) Cleaning and Disinfecting

During normal use, a POC (Point-of-Care) terminal may become dirty and should be cleaned regularly.

- 1) Prepare a cleaning agent per manufacturer's instruction or hospital protocol.
- 2) Prepare a clean cloth that has been moistened in a cleaning solution.
- 3) Wipe the POC thoroughly with a clean wipe.

Applicable Cleaning Agents List

No	Cleaning Agents	No	Cleaning Agents
1	Cidex	11	Virkon and water (1:100)
2	Isopropyl alcohol	12	DISPATCH
3	Green tintured soap	13	SDW 70C
4	Windex	14	Trigene
5	Alcohol	15	ANTIGONE WIPES
6	Alcohol 70%	16	SporeClear
7	Incidin plus	17	AntiGone
8	Incidin liquid	18	MikroBac
9	Mikrozid liquid		
10	Chloride 1000ppm		

* Do not immerse or rinse a POC terminal or its peripherals.
* Do not spray cleaning agents on the chassis
* Do not use disinfectants containing phenol