EKI-7554MI/SI

4+2 100FX Ports Managed Redundant Industrial Ethernet Switch (Wide Temp.)

User Manual

Copyright

The documentation and the software included with this product are copyrighted 2007 by Advantech Co., Ltd. All rights are reserved. Advantech Co., Ltd. reserves the right to make improvements in the products described in this manual at any time without notice. No part of this manual may be reproduced, copied, translated or transmitted in any form or by any means without the prior written permission of Advantech Co., Ltd. Information provided in this manual is intended to be accurate and reliable. However, Advantech Co., Ltd. assumes no responsibility for its use, nor for any infringements of the rights of third parties, which may result from its use.

Acknowledgements

Intel and Pentium are trademarks of Intel Corporation. Microsoft Windows and MS-DOS are registered trademarks of Microsoft Corp. All other product names or trademarks are properties of their respective owners.

Part No. Printed in China 1st Edition January 2008

EKI-7554MI-SI User Manual

Product Warranty (2 years)

Advantech warrants to you, the original purchaser, that each of its products will be free from defects in materials and workmanship for two years from the date of purchase.

This warranty does not apply to any products which have been repaired or altered by persons other than repair personnel authorized by Advantech, or which have been subject to misuse, abuse, accident or improper installation. Advantech assumes no liability under the terms of this warranty as a consequence of such events.

Because of Advantech's high quality-control standards and rigorous testing, most of our customers never need to use our repair service. If an Advantech product is defective, it will be repaired or replaced at no charge during the warranty period. For out-of-warranty repairs, you will be billed according to the cost of replacement materials, service time and freight. Please consult your dealer for more details.

If you think you have a defective product, follow these steps:

- 1. Collect all the information about the problem encountered. (For example, CPU speed, Advantech products used, other hardware and software used, etc.) Note anything abnormal and list any onscreen messages you get when the problem occurs.
- 2. Call your dealer and describe the problem. Please have your manual, product, and any helpful information readily available.
- 3. If your product is diagnosed as defective, obtain an RMA (return merchandize authorization) number from your dealer. This allows us to process your return more quickly.
- 4. Carefully pack the defective product, a fully-completed Repair and Replacement Order Card and a photocopy proof of purchase date (such as your sales receipt) in a shippable container. A product returned without proof of the purchase date is not eligible for warranty service.
- 5. Write the RMA number visibly on the outside of the package and ship it prepaid to your dealer.

Declaration of Conformity

CE

This product has passed the CE test for environmental specifications. Test conditions for passing included the equipment being operated within an industrial enclosure. In order to protect the product from being damaged by ESD (Electrostatic Discharge) and EMI leakage, we strongly recommend the use of CE-compliant industrial enclosure products.

FCC Class A

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Technical Support and Assistance

- Step 1. Visit the Advantech web site at <u>www.advantech.com/support</u> where you can find the latest information about the product.
- Step 2. Contact your distributor, sales representative, or Advantech's customer service center for technical support if you need additional assistance. Please have the following information ready before you call:
 - Product name and serial number
 - Description of your peripheral attachments
 - Description of your software (operating system, version, application software, etc.)
 - A complete description of the problem
 - The exact wording of any error messages

Safety Instructions

- 1. Read these safety instructions carefully.
- 2. Keep this User's Manual for later reference.
- 3. Disconnect this equipment from any AC outlet before cleaning. Use a damp cloth. Do not use liquid or spray detergents for cleaning.
- 4. For plug-in equipment, the power outlet socket must be located near the equipment and must be easily accessible.
- 5. Keep this equipment away from humidity.
- 6. Put this equipment on a reliable surface during installation. Dropping it or letting it fall may cause damage.
- 7. The openings on the enclosure are for air convection. Protect the equipment from overheating. DO NOT COVER THE OPENINGS.
- 8. Make sure the voltage of the power source is correct before connecting the equipment to the power outlet.
- 9. Position the power cord so that people cannot step on it. Do not place anything over the power cord.
- 10. All cautions and warnings on the equipment should be noted.
- 11. If the equipment is not used for a long time, disconnect it from the power source to avoid damage by transient overvoltage.
- 12. Never pour any liquid into an opening. This may cause fire or electrical shock.
- 13. Never open the equipment. For safety reasons, the equipment should be opened only by qualified service personnel.
- 14. If one of the following situations arises, get the equipment checked by service personnel:
 - a. The power cord or plug is damaged.
 - b. Liquid has penetrated into the equipment.
 - c. The equipment has been exposed to moisture.
 - d. The equipment does not work well, or you cannot get it to work according to the user's manual.
 - e. The equipment has been dropped and damaged.
 - f. The equipment has obvious signs of breakage.
- 15. DO NOT LEAVE THIS EQUIPMENT IN AN ENVIRONMENT WHERE THE STORAGE TEMPERATURE MAY GO BELOW -40 (-40) OR ABOVE 85 (185). THIS COULD DAMAGE THE EQUIPMENT. THE EQUIPMENT SHOULD BE IN A CONTROLLED ENVIRONMENT.

Safety Precaution - Static Electricity

Follow these simple precautions to protect yourself from harm and the products from damage.

- 1. To avoid electrical shock, always disconnect the power from your PC chassis before you work on it. Don't touch any components on the CPU card or other cards while the PC is on.
- 2. Disconnect power before making any configuration changes. The sudden rush of power as you connect a jumper or install a card may damage sensitive electronic components.

Contents

Chapter 1	Overview	2
• 1.1	Introduction	2
	1.1.1 High-Speed Transmissions	2
	1.1.2 Dual Power Input	2
	1.1.3 Flexible Mounting	2
	1.1.4 Advanced Protection	2
	1.1.5 Wide Operating Temperature	2
	1.1.6 Easy Troubleshooting	2
1.2	Features	3
1.3	Specification	4
1.4	Packing List	6
1.5	Safety Precaution	6
Chapter 2	Installation	8
21	I FD Indicators	8
	Table 2.1: EKI-7554MI/SI LED Definition	8
2.2	Dimensions (units: mm)	9
	Figure 2.1: Front View of EKI-7554MI/SI	9
	Figure 2.2: Side View of EKI-7554MI/SI	10
	Figure 2.3: Rear View of EKI-7554MI/SI	11
0.0	Figure 2.4: Top View of EKI-7554MI/SI	12
2.3		.13
	2.3.1 Wall mounting	.13
	Figure 2.5: Combine the Metal Mounting Kit (units	:
	2 3 2 DIN-rail Mounting	۲۱ 1 <i>۸</i>
	Figure 2 6: Installation to DIN-rail Step 1	14
	Figure 2.7: Installation to DIN-rail Step 2	15
2.4	Network Connection	.16
2.5	Power Connection	. 17
	Figure 2.8: Pin Assignment of the Power Connector	:17
Chapter 3	Configuration	20
• 3.1	RS-232 Console	.20
	Figure 3.1: Open Hyper Terminal	20
	Figure 3.2: COM Port Properties Setting	21
	Figure 3.3: Login Screen: RS-232 Configuration	21
	Figure 3.4: Command Line Interface	22
	3.1.1 Commands Level	.22
	1 able 3.1: Command Level 2 1 2 Commanda Sat Liat	22
	J. I.Z UUIIIIIIdillus Jel List	. 23
	3 1 3 System Commande Set	∠⊃ ??
	Table 3 3: System Commands Set	. 23
	3 1 4 Port Commands Set	23 24
		· ·

	Table 3.4: Port Commands Set	24
	3.1.5 Trunk Commands Set	.25
	Table 3.5: Trunk Commands Set	
	3 1 6 VI AN Commands Set	26
	Table 3 6: VI AN Commands Set	· 2 0
	2 1 7 Spanning Trop Commands Set	20 27
	5.1.7 Spanning Tree Commanus Set	. 21
	Table 3.7: Spanning Tree Commands Set	27
	3.1.8 QUS Commands Set	.28
	Table 3.8: QOS Commands Set	28
	3.1.9 IGMP Commands Set	.28
	Table 3.9: QOS Commands	28
	3.1.10 Mac/Filter Table Commands Set	. 28
	Table 3.10: Mac/Filter Table Commands Set	29
	3.1.11 SNMP Commands Set	.29
	Table 3.11: SNMP Commands Set	29
	3 1 12 Port Mirroring Commands Set	30
	Table 3 12: Port Mirroring Commands Set	30
	3 1 13 802 1x Commande Set	רב סכ
	Table 2.12: 902 1x Commands Set	. 30
	2.4.4.4. TETD Commondo Cot	30
	3.1.14 IFIP Commands Set	.31
	Table 3.14: TFTP Commands Set	31
	3.1.15 SystemLog, SMTP and Event	.31
	Table 3.15: SysLog,SMTP,Event Commands Set	31
	3.1.16 SNTP Commands Set	. 32
	Table 3.16: SNTP Commands Set	32
	3.1.17 X-ring Commands Set	.33
	Table 3.17: X-ring Commands Set	33
3.2	Web Browser	. 34
	Figure 3.5: Type the address in the URL	34
	Figure 3.6: Web Login Window	34
	Figure 3.7: Main page	35
	3 2 1 System	35
	Figure 3.8: System Information	36
	Figure 3.9: IP Configuration	
	Figure 3.10: DHCP Server - System Configuration	38
	Figure 3 11: DHCP Server – Client Entries	38
	Figure 3.12: DHCP Server – Port and IP Binding	
	Figure 3.13: TFTP – Update Firmware	
	Figure 3.14: TFTP – Restore Configuration	40
	Figure 3.15: TFTP – Backup Configuration	40
	Figure 3.16: Syslog Configuration	41
	Figure 3.17: SMTP Configuration	42
	Figure 3.18: Event Configuration	43
	Figure 3.19: Fault Relay Alarm	43
	Table 3.18: UTC Timezone	44
	Figure 3.20: SNTP Configuration	45
	Figure 3.21: IP Security	46
	Figure 3.22: User Authentication	47

	3.2.2	Port	.48
	-	Figure 3.23: Port Statistics	48
		Figure 3.24: Port Control	49
		Figure 3.25: Aggregator Setting	50
		Figure 3.26: 2 work ports with LACP disabled	51
		Figure 3.27: Static trunking group of 2 ports	51
		Figure 3.28: Aggregator Information	52
		Figure 3.29: State Activity	52
		Figure 3.30: Port Mirroring	53
		Figure 3.31: Rate Limiting	54
	3.2.3	Protocol	. 55
		Figure 3.32: VLAN Configuration	55
		Figure 3.33: Port based mode	56
		Figure 3.34: Port based mode-Add interface	56
		Figure 3.35: Port based mode-Edit/Delete interface .	57
		Figure 3.36: 802.1Q VLAN Configuration	58
		Figure 3.37: Edit Group Configuration interface	59
		Figure 3.38: 802.1Q Group Configuration—Edit	59
		Figure 3.39: RSTP System Configuration interface	60
		Figure 3.40: RSTP Port Configuration interface	61
		Figure 3.41: SNMP System Configuration interface.	62
		Figure 3.42: Trap Configuration interface	63
		Figure 3.43: SNMP V3 Configuration interface	64
		Figure 3.44: QoS Configuration interface	66
		Table 3.19: IGMP types Eigene 2.45: IGMP Configuration interface	6/
		Figure 3.45: IGMP Configuration interface	08
		Figure 3.40: A-ring interface	
	2 2 4	Figure 5.47: LLDP Configuration interface	
	3.2.4		. / I
		Figure 3.48: 802.1x/Radius System Configuration	71
			/ 1
		Figure 3.49: 802.1x/Radius - Port Setting interface	12
		Figure 5.50: 802.1X/Radius - Misc Configuration	70
		Figure 3.51: Static MAC Addresses interface	12
		Figure 3.52: MAC Filtering interface	73 74
		Figure 3.52: MIAC Address interface	
		Figure 3.54: All MAC Address interface	
		Figure 3.55: Factory Default interface	
		Figure 3.56: Save Configuration interface	76
		Figure 3.57: System Reboot interface	76
Chanter 1	Tro	ibleshooting	78
			1 U 04
Appendix A	PII	n Assignment & Wiring	81
		Figure A.1: RJ-45 Pin Assignment	81
		Figure A.2: EIA/TIA-568B	81
		Figure A.3: EIA/TIA-568A	81
		Figure A.4: DB 9-pin female connector	82

CHAPTER

Overview

Sections include:

- Introduction
- Features
- Specifications
- Packing List
- Safety Precaution

Chapter 1 Overview

1.1 Introduction

To create reliability in your network, the EKI-7554MI/SI comes equipped with a proprietary redundant network protocol—X-Ring that was developed by Advantech, which provides users with an easy way to establish a redundant Ethernet network with ultra high-speed recovery time less than 10 ms.

Aside from 4 x 10/100Base-TX fast Ethernet ports, the EKI-7554MI/SI comes equipped with 2 100Mbps fiber expansion ports. The fiber ports can be used for the application of wideband uploading and long distance transmissions to fit the field request flexibility.

1.1.1 High-Speed Transmissions

The EKI-7554MI/SI includes a switch controller that can automatically sense transmission speeds (10/100 Mbps). The RJ-45 interface can also be auto-detected, so MDI or MDI-X is automatically selected and a crossover cable is not required. All Ethernet ports have memory buffers that support the store-and-forward mechanism. This assures that data is properly transmitted.

1.1.2 Dual Power Input

To reduce the risk of power failure, EKI-7554MI/SI provides +12 \sim 48 V_{DC} dual power inputs. If there is power failure, EKI-7554MI/SI will automatically switch to the secondary power input.

1.1.3 Flexible Mounting

EKI-7554MI/SI is compact and can be mounted on a DIN-rail or panel, so it is suitable for any space-constrained environment.

1.1.4 Advanced Protection

The power line of EKI-7554MI/SI supports up to 3,000 V_{DC} EFT protection, which secure equipment against unregulated voltage and make systems safer and more reliable. Meanwhile, 4,000 V_{DC} ESD protections for Ethernet ports make EKI-7554MI/SI more suitable for harsh environments.

1.1.5 Wide Operating Temperature

The operating temperature of the EKI-7554MI/SI is between -40 ~ 75° C. With such a wide range, you can use the EKI-7554MI/SI in some of the harshest industrial environments that exist.

1.1.6 Easy Troubleshooting

LED indicators make troubleshooting quick and easy. Each 10/100 Base-TX port has 2 LEDs that display the link status, transmission speed and collision status. Also the indicators PWR, PWR1, PWR2, R.M., and P-Fail help you diagnose immediately.

1.2 Features

- Provides 4 x 10/100 Mbps Ethernet ports with RJ45 connector
- Provides 2 x 100 Mbps single-mode SC type fiber ports (EKI-7554MI: Multi-mode; EKI-7554SI: Single mode.)
- Redundancy: X-Ring (ultra high-speed recovery time<10ms), RSTP/STP (802.1w/1D)
- Management: Web, Telnet, Serial Console, Windows Utility and SNMP
- Control: VLAN/GVRP, QOS, IGMP Snooping, LACP, and Rate Limit
- Security: IP/MAC and port binding, DHCP Server, IP access list, 802.1x, SNMPv3
- Diagnostic: Port Statistic, Port Mirroring, RMON, Trap, SNMP Alert, and Syslog
- Dual 12 ~ 48 V_{DC} power input and 1 Relay Output
- Supports wide operating temperature from -40°C ~ 75° C
- Robust mechanism and special heat spreader design

Communications

Standard

LAN Transmission Distance

Transmission Speed

IEEE 802.3, 802.3ad, 802.3u, 802.3x IEEE 802.1D, 802.1w, 802.1p, 802.1Q, 802.1X, 802.1ab 10/100Base-TX, 100Base-FX Ethernet: Up to 100 m Single Mode Fiber: Up to 30 km Up to 100 Mbps

Interface

Connectors

LED Indicators Console

8 x RJ-45 2 x SC type fiber connectors 6-pin removable screw terminal (power & relay) PWR, PWR1, PWR2, R.M., P-Fail, 10/100 Mbps RS-232 (RJ-45)

Power

Power ConsumptionMax. 7.7WPower Input2 x Unregulated +12 ~ 48 V_{DC} (0.65A max.)Overload Current Protection1.6A@12V_{DC} (Re-settable Fuse)Fault Output1 Relay Output

Mechanism

Dimensions (WxHxD) Enclosure Mounting 79 x 152 x 105 mm IP30, metal shell with solid mounting kits DIN-rail, wall

Protection

ESD (Ethernet) Surge (EFT for power) Reverse Polarity 4,000 V_{DC} 3,000 V_{DC} Present

Environment

Operating Temperature	-10 ~ 60°C (standard model)
	$-40 \sim 75^{\circ}$ C (wide operating temp. model)

Operating Humidity Storage Temperature Storage Humidity MTBF

Certifications

Safety EMC $5 \sim 95\%$ (non-condensing) -40 ~ 85°C (-40 ~ 185°F) 0 ~ 95% (non-condensing) 284,455 hours

UL, 60950-1, CAN/CSA-C22.2 No.60950 EU: EN55011, EN61000-6-4 EN55022, Class A, EN61000-3-2/3 EN55024 IEC61000-4-2/3/4/5/6/8 EN61000-6-2 IEC60068-2-32 IEC60068-2-7 IEC60068-2-6

Freefall Shock Vibration

1.4 Packing List

- 1 x EKI-7554MI/SI Industrial Managed Gigabit Ethernet Switch
- 1 x eAutomation Industrial Communication CD-ROM with software, and User manual
- 2 x Wall Mounting Bracket and Screws
- 1 x DIN-rail Mounting Bracket and Screws
- 1 x 8-pin RJ-45 to RS-232 serial cable
- 1 x DC Jack Cable 2.0/150mm
- 1 x EKI-7554MI/SI Startup Manual

1.5 Safety Precaution

Attention IF DC voltage is supplied by an external circuit, please use a protection device on the power supply input.

CHAPTER CHAPTER

Installation

Sections include:

- LED Indicators
- Dimensions
- Mounting
- Network Connection
- Connection to a Fiber Optic Network
- Power Connection

Chapter 2 Installation

In this chapter, you will be given an overview of EKI-7554MI/SI hardware installation procedures.

2.1 LED Indicators

There are few LEDs indicate the power status and network status located on the front panel of EKI-7554MI/SI, each of them has its own specific meaning shown as below.

Table 2.1: EKI-7554MI/SI LED Definition					
LED	Color	Description			
	Groop	On	System power on		
	Green	Off	No power input		
		On	The industrial switch is the master of the X-ring group		
R.M.	Green	Off	The industrial switch is not the master of the X-ring group		
	Croon	On	Power input 1 is active		
	Green	Off	Power input 1 is inactive		
	Croon	On	Power input 2 is active		
PWR2	Green	Off	Power input 2 is inactive		
P-Fail	Red	On	Power input 1 or 2 is inactive or port link down (depends on Fault Relay Alarm configuration)		
		Off	Power input 1 and 2 are both active, or no power input		
Link/Active (5, 6)	Green	On	Connected to network		
		Flashing	Networking is active		
		Off	Not connected to network		
	Green	On	Connected to network		
Link/Active (1~4)		Flashing	Networking is active		
		Off	Not connected to network		
	Orange	On	Ethernet port full duplex		
Duplex/Collision (1~4)		Flashing	Collision of packets occurs		
		Off	Ethernet port half duplex or not connected to network		



Figure 2.1: Front View of EKI-7554MI/SI



Figure 2.2: Side View of EKI-7554MI/SI



Figure 2.3: Rear View of EKI-7554MI/SI



Figure 2.4: Top View of EKI-7554MI/SI

2.3 Mounting

The EKI-7554MI/SI supports two mounting methods: DIN-rail & Wall.

2.3.1 Wall mounting

EKI-7554MI/SI can be wall-mounted by using the included mounting kit. Then, hang on the EKI-7554MI/SI to the nails on the wall.

First, use the screws included in the package to combine the EKI-7554MI/SI and metal mounting kit. And then you can install the device firmly via the components, please see Figure 2.5 as below.



Figure 2.5: Combine the Metal Mounting Kit (units: mm)

2.3.2 DIN-rail Mounting

You can also mount EKI-7554MI/SI on a standard DIN-rail by steps below.

The DIN-rail kit is screwed on the industrial switch when out of factory. If the DIN-rail kit is not screwed on the industrial switch, please screw the DIN-rail kit on the switch first.

First, hang the EKI-7554MI/SI to the DIN-rail with angle of inclination. See Figure 2.6.



Figure 2.6: Installation to DIN-rail Step 1

Then, let the device down straight to slide over the rail smoothly. See Figure 2.7.



Figure 2.7: Installation to DIN-rail Step 2

2.4 Network Connection

EKI-7554MI/SI has 4 x RJ-45 ports that support connection to 10 Mbps Ethernet, or 100 Mbps Fast Ethernet, and half or full duplex operation. EKI-7554MI/SI can be connected to other hubs or switches via a twisted-pair straight-through or crossover cable up to 100m long. The connection can be made from any TX port of EKI-7554MI/SI (MDI-X) to another hub or switch either MDI-X or uplink MDI port. Besides, EKI-7554MI/SI provides 2 x SC type fiber ports for long distance uplinks up to 30km (single mode).

EKI-7554MI/SI supports auto-crossover to make networking more easy and flexible. You can connect any RJ-45 (MDI-X) port on the switch to any device such as a switch, bridge or router.

2.5 Power Connection

The EKI-7554MI/SI supports dual +12 \sim 48 V_{DC} power inputs and power-fail relay output.



Figure 2.8: Pin Assignment of the Power Connector

You can connect an alarm indicator, buzzer or other signaling equipment through the relay output. The relay opens if power input 1, 2 fails or port link down/break ("Open" means if you connect relay output with an LED, the light would be off).

CHAPTER

Configuration

Sections include:

- RS-232 Console
- Web Browser
- Mounting
- Self Diagnosis

Chapter 3 Configuration

The EKI-7554MI/SI can be configured in two ways: via RS-232 Console or a web browser.

3.1 RS-232 Console

EKI-7554MI/SI's RS-232 console is designed for rapidly configuring which provides the console management—CLI command.

Attach the supplied cable, which one end is RJ-45 and the other end is female DB9, to connect EKI-7554MI/SI and your host PC or terminal. The connected PC or terminal must support the terminal emulation program.



From the Windows desktop, click: Start/Programs/Accessories/Communications/HyperTerminal to open Hyper Terminal program.



Figure 3.1: Open Hyper Terminal

Select the appropriate COM port, and set the parameter as Fig.3.2 (9600 for Baud Rate, 8 for Data Bits, None for Parity, 1 for Stop Bits, and None for Flow Control).

Bits per second	9600	•
Data bits	8	•
Parity	None	
Stop bits	1	
Flow control	None	E

Figure 3.2: COM Port Properties Setting

Press **Enter** for login screen (If you can not find the login screen, press **Enter** one more time). The default user name and password are both "**admin**". Key-in the user name and password to enter the command line interface.



Figure 3.3: Login Screen: RS-232 Configuration

After you have logged in to the system, you will see a command prompt. To enter CLI management interface, type in "**enable**" command.

switch#_ switch#_

Figure 3.4: Command Line Interface

The following table lists the CLI commands and description.

3.1.1 Commands Level

Table 3.1: Command Level					
Modes	Access Method	Prompt	Exit Method	About This Model	
User EXEC	Begin a session with your switch.	switch>	Enter logout or quit .	The user commands available at the user level are a subset of those available at the privileged level. Use this mode to • Perform basic tests. • Display system information.	
Privileged EXEC	Enter the enable command while in user EXEC mode.	switch#	Enter disable to exit.	The privileged command is the advance mode Use this mode to • Display advanced function status • save configuration	
Global configuration	Enter the configure command while in privileged EXEC mode.	switch(config)#	To exit to privileged EXEC mode, enter exit or end	Use this mode to configure the parameters that are going to be applied to your switch	
VLAN database	Enter the vlan database command while in privileged EXEC mode.	switch(vlan)#	To exit to user EXEC mode, enter exit .	Use this mode to configure VLAN-specific parameters.	
Interface configuration	Enter the interface command (with a specific interface) while in global configuration mode	switch(config-if)#	To exit to global configuration mode, enter exit . To exist to privileged EXEC mode, enter exit or end .	Use this mode to configure the parameters for the switch and Ethernet ports.	

3.1.2 Commands Set List

Table 3.2: Commands Set List				
Command	Code Word			
User EXEC	E			
Privileged EXEC	Р			
Global configuration	G			
VLAN database	v			
Interface configuration	I			

3.1.3 System Commands Set

Table 3.3: System Command	ls Set		
Netstar Commands	Level	Description	Example
show config	E	Show switch configuration	switch> show config
show terminal	Р	Show console information	switch#show terminal
write memory	Р	Save user configuration into permanent memory (flash rom)	switch#write memory
system name [System Name]	G	Configure system name	switch(config)#system name xxx
system location [System Location]	G	Set switch system location string	switch(config)#system location xxx
system description [System Description]	G	Set switch system description string	switch(config)#system description xxx
system contact [System Contact]	G	Set switch system contact window string	switch(config)#system contact xxx
show system-info	E	Show system information	switch>show system-info
ip address [Ip-address] [Subnet-mask] [Gateway]	G	Configure the IP address of switch	switch(config)#ip address 192.168.1.1 255.255.255.0 192.168.1.254
ip dhcp	G	Enable DHCP client function of switch	switch(config)#ip dhcp
show ip	Р	Show IP information of switch	switch#show ip
no ip dhcp	G	Disable DHCP client function of switch	switch(config)#no ip dhcp
reload	G	Halt and perform a cold restart	switch(config)#reload
default	G	Restore to default	switch(config)#default
admin username [Username]	G	Changes a login username. (maximum 10 words)	switch(config)#admin username xxxxxx
admin password [Password]	G	Specifies a password (maximum 10 words)	switch(config)#admin password xxxxxx
show admin	Р	Show administrator information	switch#show admin
dhcpserver enable	G	Enable DHCP Server	switch(config)#dhcpserver enable
Dhcpserver disable	G	Disable DHCP Server	switch(config)#no dhcpserver
dhcpserver lowip [Low IP]	G	Configure low IP address for IP pool	switch(config)#dhcpserver lowip 192.168.1.100
dhcpserver highip [High IP]	G	Configure high IP address for IP pool	switch(config)#dhcpserver highip 192.168.1.200

dhcpserver subnetmask [Subnet mask]	G	Configure subnet mask for DHCP clients	switch(config)#dhcpserver subnetmask 255.255.255.0
dhcpserver gateway [Gateway]	G	Configure gateway for DHCP clients	switch(config)#dhcpserver gateway 192.168.1.254
dhcpserver dnsip [DNS IP]	G	Configure DNS IP for DHCP clients	switch(config)#dhcpserver dnsip 192.168.1.1
dhcpserver leasetime [Hours]	G	Configure lease time (in hour)	switch(config)#dhcpserver leasetime 1
dhcpserver ipbinding [IP address]	I	Set static IP for DHCP clients by port	switch(config)#interface fastEthernet 2 switch(config)#dhcpserver ipbinding 192.168.1.1
show dhcpserver configuration	Р	Show configuration of DHCP server	switch#show dhcpserver configuration
show dhcpserver clients	Р	Show client entries of DHCP server	switch#show dhcpserver clients
show dhcpserver ip-binding	Р	Show IP-Binding information of DHCP server	switch#show dhcpserver ip-binding
no dhcpserver	G	Disable DHCP server function	switch(config)# no dhcpserver
security enable	G	Enable IP security function	switch(config)# security enable
security http	G	Enable IP security of HTTP server	switch(config)# security http
security telnet	G	Enable IP security of telnet server	switch(config)# security telnet
security ip [Index(110)] [IP Address]	G	Set the IP security list	switch(config)# security ip 1 192.168.1.55
show security	Р	Show the information of IP security	switch# show security
no security	G	Disable IP security function	switch(config)# no security
no security http	G	Disable IP security of HTTP server	switch(config)#no security http
no security telnet	G	Disable IP security of telnet server	switch(config)#no security telnet

3.1.4 Port Commands Set

Table 3.4: Port Commands Set			
Netstar Commands	Level	Description	Example
interface fastEthernet [Portid]	G	Choose the port for modification.	switch(config)#interface fastEthernet 2
duplex [full half]	I	Use the duplex configuration command to specify the duplex mode of operation for Fast Ethernet.	switch(config)#interface fastEthernet 2 switch(config-if)#duplex full
speed [10 100 1000 auto]	I	Use the speed configuration command to specify the speed mode of operation for Fast Ethernet., the speed can't be set to 1000 if the port isn't a giga port	switch(config)#interface fastEthernet 2 switch(config-if)#speed 100
no flowcontrol	I	Disable flow control of interface	switch(config-if)# no flowcontrol
security enable	I	Enable security of interface	switch(config)#interface fastEthernet 2 switch(config-if)#security enable
no security	I	Disable security of interface	switch(config)#interface fastEthernet 2 switch(config-if)#no security

bandwidth type all	I	Set interface ingress limit frame type to "accept all frame"	switch(config)#interface fastEthernet 2 switch(config-if)#bandwidth type all
bandwidth type broadcast-multicast- flooded-unicast	I.	Set interface ingress limit frame type to "accept broadcast, multicast, and flooded unicast frame"	switch(config)#interface fastEthernet 2 switch(config-if)#bandwidth type broadcast- multicast-flooded-unicast
bandwidth type broadcast-multicast	I.	Set interface ingress limit frame type to "accept broadcast and multicast frame"	switch(config)#interface fastEthernet 2 switch(config-if)#bandwidth type broadcast- multicast
bandwidth type broadcast-only	I	Set interface ingress limit frame type to "only accept broadcast frame"	<pre>switch(config)#interface fastEthernet 2 switch(config-if)#bandwidth type broadcast-only</pre>
bandwidth in [Value]	I	Set interface input bandwidth. Rate Range is from 100 kbps to 102400 kbps or to 256000 kbps for giga ports, and zero means no limit.	switch(config)#interface fastEthernet 2 switch(config-if)#bandwidth in 100
bandwidth out [Value]		Set interface output bandwidth. Rate Range is from 100 kbps to 102400 kbps or to 256000 kbps for giga ports, and zero means no limit.	switch(config)#interface fastEthernet 2 switch(config-if)#bandwidth out 100
show bandwidth	I	Show interfaces bandwidth control	switch(config)#interface fastEthernet 2 switch(config-if)#show bandwidth
state [Enable Disable]	I	Use the state interface configuration command to specify the state mode of operation for Ethernet ports. Use the disable form of this command to disable the port.	switch(config)#interface fastEthernet 2 switch(config-if)#state Disable
show interface configuration	I.	show interface configuration status	switch(config)#interface fastEthernet 2 switch(config-if)#show interface configuration
show interface status	I	show interface actual status	switch(config)#interface fastEthernet 2 switch(config-if)#show interface status
show interface accounting	I	show interface statistic counter	switch(config)#interface fastEthernet 2 switch(config-if)#show interface accounting
no accounting	Т	Clear interface accounting information	switch(config)#interface fastEthernet 2 switch(config-if)#no accounting

3.1.5 Trunk Commands Set

Table 3.5: Trunk Commands Set						
Netstar Commands	Level	Description	Example			
aggregator priority [1~65535]	G	Set port group system priority	switch(config)#aggregator priority 22			
aggregator activityport [Group ID] [Port Numbers]	G	Set activity port	switch(config)#aggregator activityport 2			
aggregator group [GroupID] [Port-list] lacp workp [Workport]	G	Assign a trunk group with LACP active. [GroupID] :1~3 [Port-list]:Member port list, This parameter could be a port range(ex.1-4) or a port list separate by a comma(ex.2, 3, 6) [Workport]: The amount of work ports, this value could not be less than zero or be large than the amount of member ports.	switch(config)#aggregator group 1 1-4 lacp workp 2 or switch(config)#aggregator group 2 1,4,3 lacp workp 3			

aggregator group [GroupID] [Port-list] nolacp	G	Assign a static trunk group. [GroupID] :1~3 [Port-list]:Member port list, This parameter could be a port range(ex.1-4) or a port list separate by a comma(ex.2, 3, 6)	switch(config)#aggregator group 1 2-4 nolacp or switch(config)#aggregator group 1 3,1,2 nolacp
show aggregator	Ρ	Show the information of trunk group	switch#show aggregator 1 or switch#show aggregator 2 or switch#show aggregator 3
no aggregator lacp [GroupID]	G	Disable the LACP function of trunk group	switch(config)#no aggreator lacp 1
no aggregator group [GroupID]	G	Remove a trunk group	switch(config)# no aggreator group 2

3.1.6 VLAN Commands Set

Table 3.6: VLAN Commands Set						
Netstar Commands	Level	Description	Example			
vlan database	Ρ	Enter VLAN configure mode	switch#vlan database			
Vlanmode [portbase 802.1q gvrp]	v	To set switch VLAN mode.	switch(vlan)#vlanmode portbase or switch(vlan)#vlanmode 802.1q or switch(vlan)#vlanmode gvrp			
no vlan	V	No VLAN	Switch(vlan)#no vlan			
Ported based VLAN configuration						
vlan port-based grpname [Group Name] grpid [GroupID] port [PortNumbers]	v	Add new port based VALN	switch(vlan)#vlan port-based grpname test grpid 2 port 2-4 or switch(vlan)#vlan port-based grpname test grpid 2 port 2,3,4			
show vlan [GroupID] or show vlan	v	Show VLAN information	switch(vlan)# show vlan 23			
no vlan group [GroupID]	۷	Delete port base group ID	switch(vlan) #no vlan group 2			
IEEE 802.1Q VLAN						
vlan 8021q name [GroupName] vid [VID]	v	Change the name of VLAN group, if the group didn't exist, this command can't be applied.	switch(vlan)# vlan 8021q name test vid 22			
vlan 8021q port [PortNumber] access-link untag [UntaggedVID]	۷	Assign a access link for VLAN by port, if the port belong to a trunk group, this command can't be applied.	switch(vlan)#vlan 8021q port 3 access-link untag 33			
vlan 8021q port [PortNumber] trunk-link tag [TaggedVID List]	V	Assign a trunk link for VLAN by port, if the port belong to a trunk group, this command can't be applied.	switch(vlan)#vlan 8021q port 3 trunk-link tag 2,3,6,99 or switch(vlan)#vlan 8021q port 3 trunk-link tag 3-20			
vlan 8021q port [PortNumber] hybrid-link untag [UntaggedVID] tag [TaggedVID List]	v	Assign a hybrid link for VLAN by port, if the port belong to a trunk group, this command can't be applied.	switch(vlan)#vlan 8021q port 3 hybrid-link untag 4 tag 3,6,8 or switch(vlan)#vlan 8021q port 3 hybrid-link untag 5 tag 6-8			
vlan 8021q trunk [PortNumber] access-link untag [UntaggedVID]	v	Assign a access link for VLAN by trunk group	switch(vlan)#vlan 8021q trunk 3 access-link untag 33			
---	---	---	--			
vlan 8021q trunk [PortNumber] trunk-link tag [TaggedVID List]	v	Assign a trunk link for VLAN by trunk group	switch(vlan)#vlan 8021q trunk 3 trunk-link tag 2,3,6,99 or switch(vlan)#vlan 8021q trunk 3 trunk-link tag 3- 20			
vlan 8021q trunk [PortNumber] hybrid-link untag [UntaggedVID] tag [TaggedVID List]	v	Assign a hybrid link for VLAN by trunk group	switch(vlan)#vlan 8021q trunk 3 hybrid-link untag 4 tag 3,6,8 or switch(vlan)#vlan 8021q trunk 3 hybrid-link untag 5 tag 6-8			
show vlan [GroupID] or show vlan	v	Show VLAN information	switch(vlan) #show vlan 23			
no vlan group [GroupID]	V	Delete port base group ID	switch(vlan) #no vlan group 2			

3.1.7 Spanning Tree Commands Set

Netstar Commands	Level	Description	Example
spanning-tree enable	G	Enable spanning tree	switch(config)#spanning-tree enable
spanning-tree priority [0~61440]	G	Configure spanning tree priority parameter	switch(config)#spanning-tree priority 32767
spanning-tree max-age [seconds]	G	Use the spanning-tree max-age global configuration command to change the interval between messages the spanning tree receives from the root switch. If a switch does not receive a bridge protocol data unit (BPDU) message from the root switch within this interval, it recomputed the Spanning Tree Protocol (STP) topology.	switch(config)# spanning-tree max-age 15
spanning-tree hello-time [seconds]	G	Use the spanning-tree hello-time global configuration command to specify the interval between hello bridge protocol data units (BPDUs).	switch(config)# spanning-tree hello-time 3
panning-tree forward-time [seconds]	G	Use the spanning-tree forward- time global configuration command to set the forwarding-time for the specified spanning-tree instances. The forwarding time determines how long each of the listening and learning states last before the port begins forwarding.	switch(config)# spanning-tree forward-time 20
:tp-path-cost 1~20000000]	I	Use the spanning-tree cost interface configuration command to set the path cost for Spanning Tree Protocol (STP) calculations. In the event of a loop, spanning tree considers the path cost when selecting an interface to place into the forwarding state.	switch(config)#interface fastEthernet 2 switch(config-if)#stp-path-cost 20
stp-path-priority Port Priority]	I	Use the spanning-tree port-priority interface configuration command to configure a port priority that	switch(config)#interface fastEthernet 2 switch(config-if)#stp-path-priority 128

		position as the root switch.	
stp-admin-p2p	1	Admin P2P of STP priority on this	switch(config)#interface fastEthernet 2
[Auto] I rue Faise]		interface.	switch(config-if)#stp-admin-p2p Auto
stp-admin-edge		Admin Edge of STP priority on this	switch(config)#interface fastEthernet 2
[True False]		interface.	switch(config-if)#stp-admin-edge True
stp-admin-non-stp		Admin NonSTP of STP priority on	switch(config)#interface fastEthernet 2
[True False]		this interface.	switch(config-if)#stp-admin-non-stp False
show spanning-tree	-	Displays a summary of the	switch>show spanning-tree
	-	spanning-tree states.	
no spanning-tree	G	Disable spanning-tree.	switch(config)#no spanning-tree

3.1.8 QOS Commands Set

Table 3.8: QOS Commands Set			
Netstar Commands	Level	Description	Example
qos policy [weighted-fair strict]	G	Select QOS policy scheduling	switch(config)#qos policy weighted-fair
qos prioritytype [port-based cos-only tos-only cos- first tos-first]	G	Setting of QOS priority type	switch(config)#qos prioritytype
qos priority portbased [Port] [lowest low middle high]	G	Configure Port-based Priority	switch(config)#qos priority portbased 1 low
qos priority cos [Priority][lowest low middle high]	G	Configure COS Priority	switch(config)#qos priority cos 0 middle
<pre>qos priority tos [Priority][lowest low middle high]</pre>	G	Configure TOS Priority	switch(config)#qos priority tos 3 high
show qos	Р	Displays the information of QoS configuration	Switch# show qos
no qos	G	Disable QoS function	switch(config)# no qos

3.1.9 IGMP Commands Set

Table 3.9: QOS Commands Set			
Netstar Commands	Level	Description	Example
igmp enable	G	Enable IGMP snooping function	switch(config)#igmp enable
Igmp-query auto	G	Set IGMP query to auto mode	switch(config)#Igmp-query auto
Igmp-query force	G	Set IGMP query to force mode	switch(config)#Igmp-query force
show igmp configuration	Р	Displays the details of an IGMP configuration.	switch#show igmp configuration
show igmp multi	Р	Displays the details of an IGMP snooping entries.	switch#show igmp multi
no igmp	G	Disable IGMP snooping function	switch(config)#no igmp
no igmp-query	G	Disable IGMP query	switch#no igmp-query

3.1.10 Mac/Filter Table Commands Set

Table 3.10: Mac/Filter Table Commands Set				
Netstar Commands	Level	Description	Example	
mac-address-table static hwaddr [MAC]	1	Configure MAC address table of interface (static).	switch(config)#interface fastEthernet 2 switch(config-if)#mac-address-table static hwaddr 000012345678	
mac-address-table filter hwaddr [MAC]	G	Configure MAC address table(filter)	switch(config)#mac-address-table filter hwaddr 000012348678	
show mac-address-table	Р	Show all MAC address table	switch#show mac-address-table	
show mac-address-table static	Р	Show static MAC address table	switch#show mac-address-table static	
show mac-address-table filter	Р	Show filter MAC address table.	switch#show mac-address-table filter	
no mac-address-table static hwaddr [MAC]	1	Remove an entry of MAC address table of interface (static)	switch(config)#interface fastEthernet 2 switch(config-if)#no mac-address-table static hwaddr 000012345678	
no mac-address-table filter hwaddr [MAC]	G	Remove an entry of MAC address table (filter)	switch(config)#no mac-address-table filter hwaddr 000012348678	
no mac-address-table	G	Remove dynamic entry of MAC address table	switch(config)#no mac-address-table	

3.1.11 SNMP Commands Set

[Excluded|Included]

Table 3.11: SNMP Commands Set **Netstar Commands** Level Description Example snmp system-name Set SNMP agent system name switch(config)#snmp system-name l2switch G [System Name] snmp system-location Set SNMP agent system location switch(config)#snmp system-location lab G [System Location] Set SNMP agent system contact switch(config)#snmp system-contact where snmp system-contact G [System Contact] Select the agent mode of SNMP switch(config)#snmp agent-mode v1v2cv3 snmp agent-mode G [v1v2c|v3|v1v2cv3 switch(config)#snmp community-strings public snmp community-strings [Community] Add SNMP community string. right G right rw [RO/RW] snmp-server host Configure SNMP server host switch(config)#snmp-server host 192.168.1.50 [IP address] community public trap-version v1 information and community string community (remove) G [Community-string] Switch(config)# trap-version no snmp-server host 192.168.1.50 [v1|v2c] snmpv3 context-name switch(config)#snmpv3 context-name Test Configure the context name G [Context Name switch(config)#snmpv3 user test01 group G1 snmpv3 user Configure the userprofile for password AuthPW PrivPW SNMPV3 agent. Privacy password [User Name] group could be empty. [Group Name] G password [Authentication Password] [Privacy Password] snmpv3 access context-name Configure the access table of switch(config)#snmpv3 access context-name Test [Context Name] SNMPV3 agent group G1 security-level AuthPriv group match-rule Exact views V1 V1 V1 [Group Name] security-level [NoAuthNoPriv|AuthNoPriv|AuthPriv] G match-rule [Exact|Prifix] views [Read View Name] [Write View Name] [Notify View Name] switch(config)#snmpv3 mibview view V1 type snmpv3 mibview view Configure the mibview table of [View Name] SNMPV3 agent Excluded sub-oid 1.3.6.1 G type

sub-oid [OID]			
show snmp	Р	Show SNMP configuration	switch#show snmp
no snmp community-strings [Community]	G	Remove the specified community.	switch(config)# no snmp community-strings public
no snmp-server host [Host-address]	G	Remove the SNMP server host.	switch(config)#no snmp-server 192.168.1.50
no snmpv3 user [User Name]	G	Remove specified user of SNMPv3 agent.	switch(config)# no snmpv3 user Test
no snmpv3 access context-name [Context Name] group [Group Name] security-level [NoAuthNoPriv AuthNoPriv AuthPriv] match-rule [Exact Prifix] views [Read View Name] [Write View Name] [Notify View Name]	G	Remove specified access table of SNMPv3 agent.	switch(config)#no snmpv3 access context-name Test group G1 security-level AuthPr iv match-rule Exact views V1 V1 V1
no snmpv3 mibview view [View Name] type [Excluded Included] sub-oid [OID]	G	Remove specified mibview table of SNMPV3 agent.	switch(config)#no snmpv3 mibview view V1 type Excluded sub-oid 1.3.6.1

3.1.12 Port Mirroring Commands Set

Table 3.12: Port Mirroring Commands Set				
Netstar Commands	Level	Description	Example	
monitor rx	G	Set RX destination port of monitor function	switch(config)#monitor rx	
monitor tx	G	Set TX destination port of monitor function	switch(config)#monitor tx	
show monitor	Р	Show port monitor information	switch#show monitor	
monitor [RX TX Both]	I	Configure source port of monitor function	switch(config)#interface fastEthernet 2 switch(config-if)#monitor RX	
show monitor	I.	Show port monitor information	switch(config)#interface fastEthernet 2 switch(config-if)#show monitor	
no monitor	I.	Disable source port of monitor function	switch(config)#interface fastEthernet 2 switch(config-if)#no monitor	

3.1.13 802.1x Commands Set

Table 3.13: 802.1x Commands Set			
Netstar Commands	Level	Description	Example
8021x enable	G	Use the 802.1x global configuration command to enable 802.1x protocols.	switch(config)# 8021x enable
8021x system radiusip [IP address]	G	Use the 802.1x system radius IP global configuration command to change the radius server IP.	switch(config)# 8021x system radiusip 192.168.1.1
8021x system serverport [port ID]	G	Use the 802.1x system server port global configuration command to	switch(config)# 8021x system serverport 1815

		change the radius server port	
8021x system accountport [port ID]	G	Use the 802.1x system account port global configuration command to change the accounting port	switch(config)# 8021x system accountport 1816
8021x system sharekey [ID]	G	Use the 802.1x system share key global configuration command to change the shared key value.	switch(config)# 8021x system sharekey 123456
8021x system nasid [words]	G	Use the 802.1x system nasid global configuration command to change the NAS ID	switch(config)# 8021x system nasid test1
8021x misc quietperiod [sec.]	G	Use the 802.1x misc quiet period global configuration command to specify the quiet period value of the switch.	switch(config)# 8021x misc quietperiod 10
8021x misc txperiod [sec.]	G	Use the 802.1x misc TX period global configuration command to set the TX period.	switch(config)# 8021x misc txperiod 5
8021x misc supportimeout [sec.]	G	Use the 802.1x misc supp timeout global configuration command to set the supplicant timeout.	switch(config)# 8021x misc supportimeout 20
8021x misc servertimeout [sec.]	G	Use the 802.1x misc server timeout global configuration command to set the server timeout.	switch(config)#8021x misc servertimeout 20
8021x misc maxrequest [number]	G	Use the 802.1x misc max request global configuration command to set the MAX requests.	switch(config)# 8021x misc maxrequest 3
8021x misc reauthperiod [sec.]	G	Use the 802.1x misc reauth period global configuration command to set the reauth period.	switch(config)# 8021x misc reauthperiod 3000
8021x portstate [disable reject accept authorize]	I	Use the 802.1x port state interface configuration command to set the state of the selected port.	switch(config)#interface fastethernet 3 switch(config-if)#8021x portstate accept
show 8021x	Е	Displays a summary of the 802.1x properties and also the port sates.	switch>show 8021x
no 8021x	G	Disable 802.1x function	switch(config)#no 8021x

3.1.14 TFTP Commands Set

Table 3.14: TFTP Commands Set			
Netstar Commands	Level	Description	Defaults Example
backup flash:backup_cfg	G	Save configuration to TFTP and need to specify the IP of TFTP server and the file name of image.	switch(config)#backup flash:backup_cfg
restore flash:restore_cfg	G	Get configuration from TFTP server and need to specify the IP of TFTP server and the file name of image.	switch(config)#restore flash:restore_cfg
upgrade flash:upgrade_fw	G	Upgrade firmware by TFTP and need to specify the IP of TFTP server and the file name of image.	switch(config)# upgrade lash:upgrade_fw

3.1.15 SystemLog, SMTP and Event

Table 3.15: SysLog,SMTP,Event Commands Set				
Netstar Commands	Level	Description	Example	
systemlog ip [IP address]	G	Set System log server IP address.	switch(config)# systemlog ip 192.168.1.100	

systemlog mode [client server both]	G	Specified the log mode	switch(config)# systemlog mode both
show systemlog	E	Displays system log.	switch>show systemlog
show systemlog	Р	Show system log client & server information	switch#show systemlog
no systemlog	G	Disable systemlog functon	switch(config)#no systemlog
smtp enable	G	Enable SMTP function	switch(config)#smtp enable
smtp serverip [IP address]	G	Configure SMTP server IP	switch(config)#smtp serverip 192.168.1.5
smtp authentication	G	Enable SMTP authentication	switch(config)#smtp authentication
smtp account [account]	G	Configure authentication account	switch(config)#smtp account User
smtp password [password]	G	Configure authentication password	switch(config)# smtp password
smtp rcptemail [Index] [Email address]	G	Configure Rcpt e-mail Address	switch(config)#smtp rcptemail 1 <u>Alert@test.com</u>
show smtp	Р	Show the information of SMTP	switch#show smtp
no smtp	G	Disable SMTP function	switch(config)#no smtp
event device-cold-start [Systemlog SMTP Both]	G	Set cold start event type	switch(config)#event device-cold-start both
event authentication-failure [Systemlog SMTP Both]	G	Set Authentication failure event type	switch(config)#event authentication-failure both
event X-ring-topology-change [Systemlog SMTP Both]	G	Set X - ring topology changed event type	switch(config)#event X-ring-topology-change both
event systemlog [Link-UP Link-Down Both]	1	Set port event for system log	switch(config)#interface fastethernet 3 switch(config-if)#event systemlog both
event smtp [Link-UP Link-Down Both]	1	Set port event for SMTP	switch(config)#interface fastethernet 3 switch(config-if)#event smtp both
show event	Р	Show event selection	switch#show event
no event device-cold-start	G	Disable cold start event type	switch(config)#no event device-cold-start
no event authentication-failure	G	Disable Authentication failure event type	switch(config)#no event authentication-failure
no event X-ring-topology-change	G	Disable X - ring topology changed event type	switch(config)#no event X-ring-topology-change
no event systemlog	I	Disable port event for system log	switch(config)#interface fastethernet 3 switch(config-if)#no event systemlog
no event smpt	I	Disable port event for SMTP	switch(config)#interface fastethernet 3 switch(config-if)#no event smtp
show systemlog	Ρ	Show system log client & server information	switch#show systemlog

3.1.16 SNTP Commands Set

Table 3.16: SNTP Command	ds Set		
Netstar Commands	Level	Description	Example
sntp enable	G	Enable SNTP function	switch(config)#sntp enable
sntp daylight	G	Enable daylight saving time, if SNTP function is inactive, this command can't be applied.	switch(config)#sntp daylight
sntp daylight-period [Start time] [End time]	G	Set period of daylight saving time, if SNTP function is inactive, this command can't be applied. Parameter format: [yyyymmdd-hh:mm]	switch(config)# sntp daylight-period 20060101- 01:01 20060202-01-01
sntp daylight-offset [Minute]	G	Set offset of daylight saving time, if SNTP function is inactive, this command can't be applied.	switch(config)#sntp daylight-offset 3
sntp ip [IP]	G	Set SNTP server IP, if SNTP function is inactive, this command can't be applied.	switch(config)#sntp ip 192.169.1.1
sntp timezone [Timezone]	G	Set timezone index, use "show sntp timzezone" command to get more information of index number	switch(config)#sntp timezone 22
show sntp	Р	Show SNTP information	switch#show sntp

show sntp timezone	Ρ	Show index number of time zone list	switch#show sntp timezone
no sntp	G	Disable SNTP function	switch(config)#no sntp
no sntp daylight	G	Disable daylight saving time	switch(config)#no sntp daylight

3.1.17 X-ring Commands Set

Table 3.17: X-ring Commands Set				
Netstar Commands	Level	Description	Example	
Xring enable	G	Enable X-ring	switch(config)#Xring enable	
Xring master	G	Enable ring master	switch(config)#Xring master	
Xring couplering	G	Enable couple ring	switch(config)#Xring couplering	
Xring dualhoming	G	Enable dual homing	switch(config)#Xring dualhoming	
Xring ringport [1st Ring Port] [2nd Ring Port]	G	Configure 1st/2nd Ring Port	switch(config)#Xring ringport 7 8	
Xring couplingport [Coupling Port]	G	Configure Coupling Port	switch(config)#Xring couplingport 1	
Xring controlport [Control Port]	G	Configure Control Port	switch(config)#Xring controlport 2	
Xring homingport [Dual Homing Port]	G	Configure Dual Homing Port	switch(config)#Xring homingport 3	
show Xring	Р	Show the information of X - Ring	switch#show Xring	
no Xring	G	Disable X-ring	switch(config)#no Xring	
no Xring master	G	Disable ring master	switch(config)# no Xring master	
no Xring couplering	G	Disable couple ring	switch(config)# no Xring couplering	
no Xring dualhoming	G	Disable dual homing	switch(config)# no Xring dualhoming	

3.2 Web Browser

EKI-7554MI/SI provides a convenient configuring way via web browser. You can follow the steps below to access EKI-7554MI/SI.

EKI-7554MI/SI's default IP is 192.168.1.1. Make sure your host PC and EKI-7659 are on the same logical sub-network.

Warning Your host PC should be in the same VLAN setting with EKI-7554MI/SI, or the management will not be configured.

Connect EKI-7554MI/SI to the Ethernet then your host PC could be configured via Ethernet. Or you can directly connect EKI-7554MI/SI to your host PC with a straight-through or cross over Ethernet cable.

Before to use web management, install the industrial switch on the network and make sure that any one of the PCs on the network can connect with the industrial switch through the web browser. The industrial switch default value of IP, subnet mask, username and password are as below:

- IP Address: 192.168.1.1
- Subnet Mask: 255.255.255.0
- Default Gateway: 192.168.1.254
- User Name: admin
- Password: admin

Open Internet Explorer and type EKI-7554MI/SI's IP in the Address field then press Enter to open the web login page.



Figure 3.5: Type the address in the URL



Figure 3.6: Web Login Window

The default user name and password are both **admin**, fill in the user name and password then press **OK** to enter the configuration. You can change the password in the system setting.

In the main page, you can find the tree menu structure of EKI-7554MI/SI in the left side. Click the "+" symbol to unroll the hiding hyperlink, and click the hyperlink to open the function page you want to configure.



Figure 3.7: Main page

3.2.1 System

System Information

Here you can view the system information and assign the system name and location to make this switch more easily to be identified on your network.

- System Name: Assign the name of the switch. The maximum length is 64 bytes.
- System Description: Displays the description of switch. Read only cannot be modified.
- System Location: Assign the switch physical location. The maximum length is 64 bytes.
- System Contact: Enter the name of contact person or organization.
- Firmware Version: Displays the switch's firmware version.
- Kernel Version: Displays the kernel software version.
- MAC Address: Displays the unique hardware address assigned by manufacturer (default).

Warning Don't set "0" for the first segment of the subnet mask and default gateway (000.xxx.xxx.xxx). Refresh the web screen if the web could not be displayed while you change the setting.

AD\ANTECH	Inductrial Sudtab
Open all	System Information
Bystem Information System Information Profession System Information DHCP Server TFTP Transaction Southern Event Log Fault Relay Alarm System Event Prot Prot Prot Prot Security Se	System Name KI-7554MU/St System Description = 10/100TX + 2 100FX w/X-Ring & Wide Operating Temperature System Contact Apply Halp Firmware Version v1.00 Kernel Version v1.57 MAC Address 00F38FFF501

Figure 3.8: System Information

IP Configuration

User can configure the IP Settings and DHCP client function in here.

- **DHCP Client**: Enable or disable the DHCP client function. When DHCP client function is enabled, the industrial switch will be assigned an IP address from the network DHCP server. The default IP address will be replaced by the assigned IP address on DHCP server. After user click **Apply**, a popup dialog shows up. It is to inform the user that when the DHCP client is enabled, the current IP will lose and user should find the new IP on the DHCP server.
- IP Address: Assign the IP address that the network is using. If DHCP client function is enabled, and then the user doesn't need to assign the IP address. And, the network DHCP server will assign the IP address displaying in this column for the industrial switch. The default IP is 192.168.16.1.
- **Subnet Mask**: Assign the subnet mask to the IP address. If DHCP client function is enabled, and then the user does not need to assign the subnet mask.
- Gateway: Assign the network gateway for the industrial switch. The default gateway is 192.168.16.254.
- **DNS1**: The abbreviation of Domain Name Server—an Internet service that translate domain name into IP addresses. Domain name are alphabetic which are easy to be remembered. Because the Internet is based on IP address; every time you use a domain name, therefore, a DNS service must translate the name into the corresponding IP address. For example, the domain name **www.net.com** might translate to 192.168.1.1
- DNS2: The backup for DNS1. When DNS1 cannot function, DNS2 will then replace DNS1 immediately.
- And then, click Apply .

AD\ANTECH	
	Industrial Switch
Open all S Main Page Bystem System	
F Configuration DHCP Server TFTP Transaction System Event Log	1P Address 192.168.1.1 Subnet Mask 255.255.0
Fault Role Alarm BNTP RF Security	Geteway 192.168.1.254 DNS1 0.0.0.0 DNS2 0.0.0.0
Part Protocol Security Security Security Security Security Security Security Security Security	Apply Help

Figure 3.9: IP Configuration

DHCP Server—System configuration

DHCP is the abbreviation of Dynamic Host Configuration Protocol that is a protocol for assigning dynamic IP addresses to devices on a network. With dynamic addressing, a device can have a different IP address every time it connects to the network. In some systems, the device's IP address can even change while it is still connected. DHCP also supports a mix of static and dynamic IP addresses. Dynamic addressing simplifies network administration because the software keeps track of IP addresses rather than requiring an administrator to manage the task. This means that a new computer can be added to a network without the hassle of manually assigning it a unique IP address.

The system provides the DHCP server function. The system provides the DHCP server function. Having enabled the DHCP server function, the switch system can be a DHCP server.

- **DHCP Server:** Enable or Disable the DHCP Server function. Enable—the switch will be the DHCP server on your local network.
- Low IP Address: Type in an IP address. Low IP address is the beginning of the dynamic IP range. For example, dynamic IP is in the range between 192.168.1.100 ~ 192.168.1.200. In contrast, 192.168.1.100 is the Low IP address.
- High IP Address: Type in an IP address. High IP address is the end of the dynamic IP range. For example, dynamic IP is in the range between 192.168.1.100 ~ 192.168.1.200. In contrast, 192.168.1.200 is the High IP address.
- Subnet Mask: Type in the subnet mask of the IP configuration.
- Gateway: Type in the IP address of the gateway in your network.
- DNS: Type in the Domain Name Server IP Address in your network.
- Lease Time (sec): It is the time period that system will reset the dynamic IP assignment to ensure the dynamic IP will not been occupied for a long time or the server doesn't know that the dynamic IP is idle.
- And then, click Apply .

ADIANTECH				Industrial	Switch
Open at	DHCP Ser	ver - Sys	tem Co	nfiguration	6
E G Settern	System Configuration	Client 6	intries	Port and IP Binding	
P Contiguration S DHCP Server		DHCP Serve	r : Disable 💌		
TFTP Transaction System Event Log		Love IP Address	192.168.1.100		
(Fault Relay Alarm		High IP Address	192.168.1.200	0	
(N SNTP		Subnet Mask	255.255.255.0		
User Authentication		Gateway	192.168.1.254		
E Pot		DNS	0.0.0.0		
El Protocol		Lease Time (sec)	96400		
Factory Default Save Configuration System Reboot		Apply	Help		

Figure 3.10: DHCP Server - System Configuration

DHCP Client—System Configuration

When the DHCP server function is active, the system will collect the DHCP client information and displays them here.



Figure 3.11: DHCP Server – Client Entries

DHCP Server—Port and IP Bindings

You can assign a specific IP address, which is the IP in dynamic IP assign range, to the specific port. When a device is connecting to the port and asks for dynamic IP assigning, the system will assign the IP address to the connected device.

AD\ANTECH				
			Industrial Swite	ch
Open all	DHCP Serv	ver - Port and	IP Binding	
Bystem	System Configuration	Client Entries	Port and IP Binding	
PF Configuration DHCP Server TFTP Transaction System Event Log Fault Relay Alarm DHTP St P Security User Authentication		Port IP Port.01 192.168.1.102 Port.02 192.168.1.52 Port.03 192.168.1.105 Port.04 0.0.0 Port.04 0.0.0		
Port Protocol Solution Becusty		Port.06 0.0.0.0		
Seve Configuration		THE THE		

Figure 3.12: DHCP Server – Port and IP Binding

TFTP—Update Firmware

Trivial File Transfer Protocol (TFTP) is a very simple file transfer protocol, with the functionality of a very basic form of FTP. It provides the functions to allow the user to update the switch firmware. Before updating, make sure you have your TFTP server ready and the firmware image is on the TFTP server.

- TFTP Server IP Address: Fill in your TFTP server IP.
- Firmware File Name: Type in the name of firmware image.
- And then, click Apply

AD\ANTECH				
			Industrial	Switch
Open all	TFTP	- Update Firm	nware	
Bystem	Update Firmware	Restore Configuration	Backup Configuration	
IP Configuration	TFTP Server IP /	Address 192.168.1.2		
III TFTP Transactors	Firmware File	Name Smage.bin		
Fault Rolay Alarm		Apply Help		
IP Security				
 User Authentication Port 				
E Protocol				
Security Security				
Save Contiguration				
Bystem Reboot		Linda (c. Eimennana		

Figure 3.13: TFTP – Update Firmware

TFTP – Restore Configuration

You can restore the configuration from TFTP server. Before doing that, you must put the image file on TFTP server first and the switch will download back the flash image.

• TFTP Server IP Address: Fill in the TFTP server IP.

- Restore File Name: Fill in the correct file name for restoring.
- Click Apply

			Industrial	Sw
TFTP -	Res	tore Config	guration	
Update Firmware	Re	tore Configuration	Backup Configuration	
TFTP Server	IP Addres	\$ 192.168.1.2		
Restore Fil	le Name	[data.bin		
		Apply Help		
	TFTP - Update Firmware TFTP Server Restore Fi	TFTP - Res Update Firmware Res TFTP Server IP Addres Restore File Name	Update Firmware Restore Configuration TFTP Server IP Address 192.168.1.2 Restore File Name data bin Apply Holp	Inclustrial TFTP - Restore Configuration Update Firmware Restore Configuration Update Firmware Restore Configuration TFTP Server IP Address 192.108.12 Restore File Name data.bin Apply Help

TFTP—Backup Configuration

You can save current Flash ROM value from the switch to TFTP server, then go to the TFTP restore configuration page to restore the Flash ROM value.

- TFTP Server IP Address: fill in the TFTP server IP
- Backup File Name: fill the file name
- Click Apply

Openal	Industrial TFTP - Backup Configuration
Man Page J System System information	Update Firmware Restore Configuration Rackup Configuration
W IP Configuration W DHCP Server TITTP Transaction	TFTP Server IP Address 192.168,1.2 Backup File Name Idata bin
Bystem Event Log Fault Rotay Alarm ShTP Bystem Event for the second s	Apply Help



System Event Log—Syslog Configuration

Configure the system event mode to collect system log.

• Syslog Client Mode: Select the system log mode—Client Only, Server Only, or Both.

- System Log Server IP Address: Assign the system log server IP.
- When Syslog Client Mode is set as **Client Only**, the system event log will only be reserved in the switch's RAM until next reboot. When Syslog Client Mode is set as **Server Only**, the system log will only be sent to the syslog server and you have to type the IP address in the Syslog Server IP Address column. If the Syslog Client Mode is set as **Both**, the system log will be reserved in the switch's RAM and sent to server.
- Click Reload to refresh the events log.
- Click Clear to clear all current events log.
- After configuring, click Apply

ADIANTECH

	Industrial Switch
Constant System Event Log - Syslo	g Configuration
State Bystem Bystem Bystem Bystem Bystem Bystem Bystem DHCP Berver Bystem Event Lop Bystem Event Lop Bystem Event Lop Fault Rolay Alarm Bystem Event Lop Protects Bystem Event Lop Protects Bystem Reboot Strate Configuration Bystem Log Server IP Address 192.100.1. Protects Bystem Reboot Protects Bystem Reboot Bystem Reboot Bystem Reboot	Event Configuration

Figure 3.16: Syslog Configuration

System Event Log—SMTP Configuration

You can set up the mail server IP, mail account, password, and forwarded email account for receiving the event alert.

- Email Alert: Enable or disable the email alert function.
- **SMTP Server IP:** Set up the mail server IP address (when **Email Alert** enabled, this function will then be available).
- Sender: Type in an alias of the switch in complete email address format, e.g. <u>switch01@123.com</u>, to identify where the event log comes from.
- Authentication: Tick the checkbox to enable this function, configuring the email account and password for authentication (when **Email Alert** enabled, this function will then be available).
- Mail Account: Set up the email account, e.g. <u>Johnadmin</u>, to receive the alert. It must be an existing email account on the mail server, which you had set up in SMTP Server IP Address column.
- Password: Type in the password to the email account.
- **Confirm Password:** Reconfirm the password.
- Rcpt e-mail Address 1 ~ 6: You can also assign up to 6 e-mail accounts to receive the alert.

Click Apply

pen all	System Event	Log	- SMTP C	Configuratio	on
Man Page System System System	Syslog Configuration	SMT	P Configuration	Event Configuration	1
IP Configuration IDHCP Server		E-mail	Alert: Enable 💌		
TETP Transaction Sector Event Lon	SMTP Server IP A	ddress t	192.168.1.55		
K Fault Relay Alarm	Sender:	F	switchG10123.com		
N SNTP	₽ Authentication				
User Authentication	Mail Account :		johnadmin		
Port	Password :				
Becuty	Confirm Passwor	d :			
Factory Default	Ropt e-mail Addre	ss 1 :	supervisor@123.com		
Save Configuration	Rept e-mail Addre	ss 2 :			
atomic research	Rcpt e-mail Addre	ss 3 : [
	Rcpt e-mail Addre	ss 4 :			
	Ropt e-mail Addre	ss 5 :			
	Rept e-mail Addre	ss 6 : [

System Event Log—Event Configuration

When the **Syslog/SMTP** checkbox is ticked, the event log will be sent to system log server/SMTP server. Also, per port log (link up, link down, and both) events can be sent to the system log server/SMTP server with the respective checkbox ticked. After configuring, click 'Apply' to have the setting taken effect.

- System event selection: There are 4 event types—Device cold start, Device warm start, Authentication Failure, and X-ring topology change. Before you can tick the checkbox of each event type, the Syslog Client Mode column on the Syslog Configuration tab/E-mail Alert column on the SMTP Configuration tab must be enabled first.
 - Device cold start: When the device executes cold start action, the system will issue a log event.
 - > Device warm start: When the device executes warm start, the system will issue a log event.
 - > Authentication Failure: When the SNMP authentication fails, the system will issue a log event.
 - > X-ring topology change: When the X-ring topology has changed, the system will issue a log event.
- Port event selection: Also, before the drop-down menu items are available, the Syslog Client Mode column on the Syslog Configuration tab/E-mail Alert column on the SMTP Configuration tab must be enabled first. Those drop-down menu items have 3 selections—Link UP, Link Down, and Link UP & Link Down. Disable means no event will be sent to the system log server/SMTP server.
 - > Link UP: The system will issue a log message when port connection links up only.
 - > Link Down: The system will issue a log message when port connection links down only.
 - Link UP & Link Down: The system will issue a log message when port connection is up and down.

					Ind	ustrial	
Open all (1) Man Page	System E	vent	Log - E	/ent	Conf	iguratio	on
Bystem	Syslog Configura	tion]	SMTP Configuration	tion	Even	t Configuration	
W IP Configuration			System event se	lection			
() TETP Transaction		Event	Туре		Syslag	SMTP	
Bystem Event Log	Device cold	stert			P		
S SNTP	Device war	n stort			曱	R	
1P Security	Authenticati	on failure				P	
Diser Authentication	X-Ring topo	logy change			9	R	
Protocol Becurity			Port event sele	ection			
🕞 Factory Default	Port		iyslog		SMTP	1 - 144 - T	
Save Configuration	Part.01	Disable	-	Dis	able	*	
Car of second second	Purt.02	Link Up		Dis	able		
	Port.03	Link Dow	Link Down	Dis	able	*	
	Port.04	Disable	-	Dist	able	*	
	Port.05	Disable		Dis	able		
	Part 06	Disable	*	Dis	able	*	

Figure 3.18: Event Configuration

Fault Relay Alarm

- Power Failure: Tick the checkbox to enable the function of lighting up the FAULT LED on the panel when power fails.
- Port Link Down/Broken: Tick the checkbox to enable the function of lighting up FAULT LED on the panel when ports' states are link-down or broken.

	1100
Fault Relay Alarm	
Power Failure	
P Power 1 P Power 2	
Port Link Down/Broken	
Port 1 Port 2	
C Port 3 C Port 4	
Port 5 P Port 6	
Apply	
	Fault Relay Alarm



SNTP Configuration

You can configure the SNTP (Simple Network Time Protocol) settings which allow you to synchronize switch clocks on the Internet.

- SNTP Client: Enable/disable SNTP function to get the time from the SNTP server.
- **Daylight Saving Time:** Enable/disable daylight saving time function. When daylight saving time is enabled, you need to configure the daylight saving time period.
- UTC Timezone: Set the switch location time zone. The following table lists the different location time zone for your reference.

Table 3.18: UTC Timezone		
Local Time Zone	Conversion from UTC	Time at 12:00 UTC
November Time Zone	- 1 hour	11am
Oscar Time Zone	-2 hours	10 am
ADT - Atlantic Daylight	-3 hours	9 am
AST - Atlantic Standard EDT - Eastern Daylight	-4 hours	8 am
EST - Eastern Standard CDT - Central Daylight	-5 hours	7 am
CST - Central Standard MDT - Mountain Daylight	-6 hours	6 am
MST - Mountain Standard PDT - Pacific Daylight	-7 hours	5 am
PST - Pacific Standard ADT - Alaskan Daylight	-8 hours	4 am
ALA - Alaskan Standard	-9 hours	3 am
HAW - Hawaiian Standard	-10 hours	2 am
Nome, Alaska	-11 hours	1 am
CET - Central European FWT - French Winter MET - Middle European MEWT - Middle European Winter SWT - Swedish Winter	+1 hour	1 pm
EET - Eastern European, USSR Zone 1	+2 hours	2 pm
BT - Baghdad, USSR Zone 2	+3 hours	3 pm
ZP4 - USSR Zone 3	+4 hours	4 pm
ZP5 - USSR Zone 4	+5 hours	5 pm

ZP6 - USSR Zone 5	+6 hours	6 pm
WAST - West Australian Standard	+7 hours	7 pm
CCT - China Coast, USSR Zone 7	+8 hours	8 pm
JST - Japan Standard, USSR Zone 8	+9 hours	9 pm
EAST - East Australian Standard GST Guam Standard, USSR Zone 9	+10 hours	10 pm
IDLE - International Date Line NZST - New Zealand Standard NZT - New Zealand	+12 hours	Midnight

- SNTP Sever URL: Set the SNTP server IP address.
- Switch Timer: Displays the current time of the switch.
- **Daylight Saving Period:** Set up the Daylight Saving beginning time and Daylight Saving ending time. Both will be different in every year.
- Daylight Saving Offset (mins): For non-US and European countries, specify the amount of time for day light savings.
- Click Apply

AD\ANTECH		
		Industrial Switch
Open all	SN	ITP Configuration
System Information		SNTP Client : Enable 💌 Daylight Saving Time : Enable 💌
🛞 TETP Transaction	UTC Timezone	(GMT)Greenwich Mean Time: Dublin, Edinburgh, Lisbon, London 💌
System Event Log	SNTP Server URL	76.168.30.201
CK SNTP	Switch Timer	Monday, September 03, 2007 4:22
(A) IP Security	Daylight Saving Period	20040101 00:0 20040101 00:0
E User Authentication	Daylight Saving Offset(mins)	a
Protocol Genurtly Factory Default Save Configuration Setum Reboot		Apply Help



IP Security

IP security function allows the user to assign 10 specific IP addresses that have permission to access the switch through the web browser for the securing switch management.

- IP Security Mode: When this option is in Enable mode, the Enable HTTP Server and Enable Telnet Server checkboxes will then be available.
- Enable HTTP Server: When this checkbox is ticked, the IP addresses among Security IP1 ~ IP10 will be allowed to access this switch via HTTP service.
- Enable Telnet Server: When this checkbox is ticked, the IP addresses among Security IP1 ~ IP10 will be allowed to access this switch via telnet service.

- Security IP 1 ~ 10: The system allows the user to assign up to 10 specific IP addresses for access security. Only these 10 IP addresses can access and manage the switch through the HTTP/Telnet service.
- And then, click Apply to have the configuration taken effect.

Remember to execute the "Save Configuration" action, otherwise the new configuration will lose when switch power off.

Industrial Swite	h
IP Security Mode: Enable F Enable HTTP Server F Enable Teinet Server Security IP1 192.168.1.77 Security IP2 192.168.1.09 Security IP3 192.168.1.120 Security IP3 192.168.1.120 Security IP5 0.0.0.0 Security IP5 0.0.0.0 Security IP5 0.0.0.0 Security IP5 0.0.0.0 Security IP5 0.0.0.0 Security IP9 0.0.0.0 Security IP1 0.0	in
	IP Security Mode: Enable C P Enable HTTP Server P Enable Telnet Server Security IP1 102.168.1.77 Security IP2 102.168.1.120 Security IP3 192.108.1.120 Security IP4 0.0.0.0 Security IP5 0.0.0 Security IP5 0.0.0 Security IP9 0.0.0 Security IP9 0.0.0 Security IP9 0.0.0



User Authentication

Note

Change web management login user name and password for the management security issue.

- User name: Key in the new user name (The default is "admin").
- **Password:** Key in the new password (The default is "admin").
- Confirm password: Re-type the new password.
- And then, click Apply to have the configuration taken effect.

ADIANTECH			
		Ind	lustrial Switch
Open al	User Auth	nentication	
System	User Nome :	admin	
B P Continuation	New Password :		
(N DHCP Server	Confirm Password :		
System Event Log System Event Log Fault Relay Alarm Site Shift Post Post Post Post Socurity Socurity	Popla	Help	
	Figure 3.22: User Authenti	cation	

3.2.2 Port

Port setting includes Port Statistics, Port Control, Port Trunk, Port Mirroring, and Rate Limiting. The user can use this interface to set the parameters and control the packet flow among the ports.

Port Statistics

The following information provides the current port statistic information.

- Port: Displays the port number.
- Type: Displays the media type of the port.
- Link: The status of linking—'Up' or 'Down'.
- State: The user can set the state of the port as 'Enable' or 'Disable' via Port Control. When the state is disabled, the port will not transmit or receive any packet.
- Tx Good Packet: The counts of transmitting good packets via this port.
- Tx Bad Packet: The counts of transmitting bad packets (including undersize [less than 64 bytes], oversize, CRC Align errors, fragments and jabbers packets) via this port.
- Rx Good Packet: The counts of receiving good packets via this port.
- Rx Bad Packet: The counts of receiving bad packets (including undersize [less than 64 bytes], oversize, CRC error, fragments and jabbers) via this port.
- Tx Abort Packet: The aborted packet while transmitting.
- Packet Collision: The counts of collision packet.
- Packet Dropped: The counts of dropped packet.
- Rx Bcast Packet: The counts of broadcast packet.
- Rx Mcast Packet: The counts of multicast packet.
- Click Clear to clean all counts.

										Inc	lusi	rial	SW
en all Si Main Page						Po	rt S	tatis	stics	5			
J Bystem	Port	Туре	Link	State	Tx Good Packet	Tx Bad Packet	Rx Goo Packet	f Rx Bad Packet	Tx Abort Packet	Packet Collision	Packet	RX Bcas Packet	RX Mcast Packet
(%) Port Statistics	Port.01	1001X	Up	Enable	692	D	1643	0	0	0	0	73	66
N/ Port Control	Port.02	10072	Duet	Enable	0	0	0	0	0	0	0	0	0
W. Port Trunk	Port.03	100TX	Down	Enable	0	0	0	0	0	0.	0	0	0
Ent Managers	Port.04	100TX	Down	Enable	0	0	0	0	0	0	0	0	0
To Data Limiter	Port.05	100FX	Down	Enable	0	0	0	Û	0	0	0	0	Û
Entheori	Port.06	100FX	Down	Enable	0	0	0	0	0	0	0	0	0
R Rate Limiting Protocol Becunty	Port.05 Port.06	100FX	Down	Enable	0	0	0	0	0	0	0	0	

Figure 3.23: Port Statistics

Port Control

In Port Control, you can pull down the selection items to set the parameters of each port to control the transmitting/receiving packets.

- **Port:** Select the port that you want to configure.
- State: Current port status. The port can be set to disable or enable mode. If the port state is set as 'Disable', it will not receive or transmit any packet.
- Negotiation: Auto and Force. Being set as Auto, the speed and duplex mode are negotiated automatically. When you set it as Force, you have to assign the speed and duplex mode manually.

- **Speed:** It is available for selecting when the Negotiation column is set as Force. When the Negotiation column is set as Auto, this column is read-only.
- **Duplex:** It is available for selecting when the Negotiation column is set as Force. When the Negotiation column is set as Auto, this column is read-only.
- Flow Control: Set flow control function as Enable or Disable. When enabled, once the device exceed the input data rate of another device as a result the receiving device will send a PAUSE frame which halts the transmission of the sender for a specified period of time. When disabled, the receiving device will drop the packet if too much to process.
- Security: Once the Security selection is set as 'On', any access from the device which connects to this port will be blocked unless the MAC address of the device is included in the static MAC address table. See the segment of Static MAC Table.
- Click Apply to have the configuration taken effect.

DANTECH	Industrial Switc
Ipen all	Port Control
Port Port Statustics No Port Control Se Port Trunk Port Trunk Port Mirroring Port Mirroring PortScol Security	Port State Negatiation Speed Duplex Flow Control Security Port 02 Port 02 Port 04 Port 04 Apply Help
S Factory Default	Part Group ID Type Link State Negotiation Speed Duplex Flow Control Security
Se Bystein Hebbot	Port.01 N/A 100TX Up Enable Auto 100 Full 100 Full Enable ON OFF
	Port.02 N/A 100TX Down Enable Auto 100 Full N/A Enable N/A OFF
	Port.03/N/A 100TX/Down/Enable/Auto 100 Full/N/A Enable/N/A OFF
	Port.0+ N/A 100TX Down Enable Auto 100 Full N/A Enable N/A OFF
	Port.05 N/A 100FX Down/Enable/Force 100 Full N/A Enable/N/A OFF
	Port.05/N/A 100FX/Down/Enable/Force 100 Full/N/A Enable/N/A OFF

Figure 3.24: Port Control

Port Trunk

The Link Aggregation Control Protocol (LACP) provides a standardized means for exchanging information between Partner Systems on a link to allow their Link Aggregation Control instances to reach agreement on the identity of the Link Aggregation Group to which the link belongs, move the link to that Link Aggregation Group, and enable its transmission and reception functions in an orderly manner. Link aggregation lets you group up to 4 ports into one dedicated connections. This feature can expand bandwidth to a device on the network. **LACP operation requires full-duplex mode,** more detail information refers to IEEE 802.3ad.

Aggregator setting

- System Priority: A value which is used to identify the active LACP. The switch with the lowest value has the highest priority and is selected as the active LACP.
- Group ID: There are four trunk groups to be selected. Choose the 'Group ID' and click Select
- LACP: When enabled, the trunk group is using LACP. A port which joins an LACP trunk group has to make an agreement with its member ports first. When disabled, the trunk group is a static trunk group. The advantage of having the LACP disabled is that a port joins the trunk group without any handshaking with its member ports. But member ports won't know that they should be aggregated together to form a logic trunk group.
- Work ports: This column field allows the user to type in the total number of active port up to four. With LACP trunk group, you create a trunk group by connecting two or more switches (e.g. you assign four ports to be the members of a trunk group whose work ports column field is set as two). The exceed

ports are standby (the **Aggregator Information** tab will show standby status on the exceed ports) and can be aggregated if work ports fail. If it is a static trunk group, the number of work ports must equal the total number of group member ports.

- Select the ports to join the trunk group. The system allows four ports maximum to be aggregated in a trunk group. Click Add to add the port which is focused to the left field. To remove unwanted ports, select the port and click Remov.
- When LACP enabled, you can configure LACP Active/Passive status for each port on State Activity page.
- Click Apply
- Use Apply to delete Trunk Group. Select the Group ID and click Delete

ADVANTECH	Industrial Switch
Open all Main Page Bystem	Port Trunk - Aggregator Setting Aggregator Enformation State Activity
Ref Port Stabulics Ref Port Control Ref Port Trunk	System Priority
Rate Limiting Policit	Group ID Trunk 1 · Select
E Jacosty	Work Ports 2
Rystem Reboot	Removes>
	Apply Delete Help
	Notice: The trunk function do not support GVRP and X-Ring.

Figure 3.25: Aggregator Setting

Aggregator Information

When you have set up the aggregator setting with LACP disabled, you will see the local static trunk group information as below.

ADIANTECH	Industrial Switch
Open all Su Main Page E System	Port Trunk - Aggregator Setting Aggregator Information State Activity
Fort Blakabus Fort Control Fort Control Fort Trunk Fort Mirroring Fort Mirroring Fate Limiting Fortocal	System Priority 1 Group ID Trunk 1 Select Laca Disable
System Reboot	Work Parts 2 Port.03 Port.04 Removeo.a Port.05
	Apply Delete Help Notice: The trunk function do not support GVRP and X-Ring.

Figure 3.26: 2 work ports with LACP disabled

ADIANTECH				
			Industrial	Switch
Open all	Port Trunk	 Aggregator In 	formation	
Bystem Port Port Statistics Port Control Port Trunk Port	Aggregator Setting	Appregator Information Static Trunking Group Group Key 2 Port Member 34	State Activity	

Figure 3.27: Static trunking group of 2 ports

When you have set up the aggregator setting of two interconnected switches with LACP enabled, you will see the respective LACP trunk group information as below.

ADIANTECH							
					Inc	dustria	Switch
Open all	Port Tru	ınk	- Agg	reg	ator Info	rmation	I
R J Bystem	Appregator Setting	0]	Aggregat	ter Infor	mation	Ptate Activity	
Port Statistics Port Control				Group 2		i i	
(iii) Port Trunk	,	Actor			Partner	1	
PotMiroing		Priority	1		1		
Rate Limiting		MAC	00FF383746	SC	001122334422		
E A Protocol		PortNo	Key Priority	Active	PortNo Key Priority	1	
🗄 🛄 Becunty	1	PORT3	513 1	selected	PORT3 513 1		
S Factory Default	19	PORT4	513]1	selected	PORT4 513 1		
B fave Configuration							
Bystem Reboot							

Figure 3.28: Aggregator Information

State Activity

Having set up the LACP aggregator on the tab of Aggregator Setting, you can configure the state activity for the members of the LACP trunk group. You can tick or cancel the checkbox beside the state display. When you remove the tick mark to the port and click Apply, the port state activity will change to **Passive**.

- Active: The port automatically sends LACP protocol packets.
- **Passive:** The port does not automatically send LACP protocol packets, and responds only if it receives LACP protocol packets from the opposite device.

Note

A link having either two active LACP nodes or one active node can perform dynamic LACP trunk.

A link having two passive LACP nodes will not perform dynamic LACP trunk because both ports are waiting for an LACP protocol packet from the opposite device.

ADVANTECH

Open all	Port 7	Frunk -	Stat	te Act	ivity
Warn Page Jugatam Port	Aggregator Setting	Aggregato	informat	ion]	State Activity
W Port Statistics	PortL	CP State Activi	y Port LA	CP State Acti	wity
Det Text	1	N/A	2	NJGA.	
To Post Manager	3	P Active	4	R Active	
N/ Rate Landing	5	N/A	6	N/04	
Protocol Security Security		App	y Help	ľ.	



Port Mirroring

The Port mirroring is a method for monitoring traffic in switched networks. Traffic through ports can be monitored by one specific port which means traffic goes in or out monitored (source) ports will be duplicated into mirroring (destination) port.

- **Destination Port:** There is only one port can be selected to be the destination (mirroring) port for monitoring both RX and TX traffic which come from the source port. Or, use one of two ports for monitoring RX traffic only and the other one for TX traffic only. The user can connect the mirroring port to LAN analyzer or Netxray.
- Source Port: The ports that the user wants to monitor. All monitored port traffic will be copied to mirroring (destination) port. The user can select multiple source ports by ticking the RX or TX checkboxes to be monitored.
- And then, click Apply .

					Ind	ustrial Swit
per all		Port	Mirre	oring	1	
Redem		Doction	tion Bast	Court	o Deut	62
Port .		RX	TX	RX	TX	
(ii) Port Statistics	Port.01	C	a.	P	R	1
Si Port Control	Port.02	С	C	E	R	1
Si Port Trunk	Port.03	C	c		9	
II) Rate Limiting	Port.04	C	C	P	E	-
Protocol	Port 05	C	c	P	R	
Gecuty	Port 06	æ	C	12	5	
Factory Default Save Configuration System Reboot	Partos	1	Apply He	6		

Rate Limiting

Here you can set up every port's frame limitation type and bandwidth rate.

• Ingress Limit Frame type: Select the frame type you want to filter. The frame types have 4 options for selecting: All, Broadcast/Multicast/Flooded Unicast, Broadcast/Multicast, and Broadcast only. The four frame type options are for ingress frames limitation. The egress rate only supports 'All' type.

All ports support port ingress and egress rate control. For example, assume port 1 is 10Mbps; the user can set the effective egress rate of port 1 as 1Mbps, ingress rate of 500Kbps. The switch performs the ingress rate by packet counter to meet the specified rate.

- Ingress: Enter the port effective ingress rate (The default value is "0")
- **Egress:** Enter the port effective egress rate (The default value is "0")
- And then, click Apply to make the settings taken effect.

AD\ANTECH

Open all Main Page Sul System Port Port

Port Statistics
 Port Control
 Port Control
 Port Numking
 Port Mirroring
 Post Mirroring
 Postocol
 Postocol
 Security
 Factory Detsult
 Save Configuration

System Reboot

Industrial Switch

Rate Limiting

	Ingress Limit Frame Type		Ingress		Egress	
Port.01	AE	N	0	kbps	0	kbps
Port.02	A Broadcast/Multicast/Flooded Unicast	7	(o	kbps	0	kbps
Port.03	Broadcast/Multicast Broadcast only		lo .	kbps	0	kbps
Port.04	All	٠	0	kbps	0	khps
Port.05	All	٠	0	kbps	0	kbps
Part.06	Al	٠	0	kbps	0	kbps

Rate Range is from 100 kbps to 102400 kbps or to 256800 kbps for giga ports, and zero means no limit.

Apply Help

Figure 3.31: Rate Limiting

EKI-7554MI-SI	User Manual
	Ober manna

3.2.3 Protocol

The user can set the layer 2 protocol setting via this interface.

VLAN configuration

A Virtual LAN (VLAN) is a logical network grouping that limits the broadcast domain, which would allow you to isolate network traffic, so only the members of the same VLAN will receive traffic from the ones of the same VLAN. Basically, creating a VLAN from a switch is logically equivalent of reconnecting a group of network devices to another Layer 2 switch. However, all the network devices are still plugged into the same switch physically.

The switch supports **Port-based** and **802.1Q** (tagged-based) VLAN. The default configuration of VLAN operation mode is "Disable".



Figure 3.32: VLAN Configuration

VLAN configuration—Port-based VLAN

Packets can go among only members of the same VLAN group. Note all unselected ports are treated as belonging to another single VLAN. If the port-based VLAN enabled, the VLAN-tagging is ignored.

In order for an end station to send packets to different VLAN groups, it itself has to be either capable of tagging packets it sends with VLAN tags or attached to a VLAN-aware bridge that is capable of classifying and tagging the packet with different VLAN ID based on not only default PVID but also other information about the packet, such as the protocol.

ADVANTECH Industrial Switch Open all VLAN Configuration R System R Port R Protocol VLAN Operation Mode : Port Based • Enable OVRP Protocol UN VLAN Management Vian ID : IN RETP IR SNMP Apply (A 008 IS SOMP (E X-Ring De LLOP H Security Factory Detautt 📓 Save Configuration 🔝 System Reboot Add Edit Delete Help Figure 3.33: Port based mode

- Pull down the selection item and focus on **Port Based** then press Apply to set the VLAN Operation Mode in **Port Based** mode.
- Click Add to add a new VLAN group.

ADVANTECH			Industria	I Switch			
Open all Main Page	VLAN	Config	uration				
Portection With Productor With WLAN WITH	VLAN Operato F Enable GW Management	VLWs Operation Mode : Port Based F Enable GVRP Protocol Management Man ID :					
SNMP Ors I DMP	particular in the second se	Apply					
LLDP Ecually Factory Default	Group Name VLAN ID	VLAN1					
Care Configuration	Port.05 Port.06	Add	Port.01 Port.02 Port.03 Port.04				
	Figure 3.34: Port based mo	Apply Help	rface				

- Enter the group name and VLAN ID. Add the port number having selected into the right field to group these members to be a VLAN group or remove any of them listed in the right field from the VLAN.
- And then, click Apply to have the configuration taken effect.
- You will see the VLAN displays.



- Use Delete to delete the VLAN.
- Use Edit to modify group name, VLAN ID, or add/remove the members of the existing VLAN group.
- Note Remember to execute the "**Save Configuration**" action, otherwise the new configuration will lose when switch power off.

802.1Q VLAN

Tagged-based VLAN is an IEEE 802.1Q specification standard. Therefore, it is possible to create a VLAN across devices from different switch venders. IEEE 802.1Q VLAN uses a technique to insert a "tag" into the Ethernet frames. Tag contains a VLAN Identifier (VID) that indicates the VLAN numbers.

You can create Tag-based VLAN, and enable or disable GVRP protocol. There are 256 VLAN groups to provide configuration. Enable 802.1Q VLAN, all ports on the switch belong to default VLAN of VID 1. The default VLAN can't be deleted.

GVRP (GARP VLAN Registration Protocol) is a protocol that facilitates control of virtual local area networks (VLANs) within a larger network. GVRP conforms to the IEEE 802.1Q specification, which defines a method of tagging frames with VLAN configuration data. This allows network devices to dynamically exchange VLAN configuration information with other devices.

GVRP is based on GARP (Generic Attribute Registration Protocol), a protocol that defines procedures by which end stations and switches in a local area network (LAN) can register and de-register attributes, such as identifiers or addresses, with each other.

Every end station and switch thus has a current record of all the other end stations and switches that can be reached.

802.1Q Configuration

- Pull down the selection item and focus on **802.1Q** then press Apply to set the VLAN Operation Mode in **802.1Q** mode.
- Enable GVRP Protocol: Tick the checkbox to enable GVRP protocol. This checkbox is available while the VLAN Operation Mode is in 802.1Q mode.

- Management VLAN ID: The default value is '0' which means VLAN function in 802.1Q mode is not available. While this column field is filled with a value from 1 to 4096, the member ports of this VLAN can access the management interface.
- Select the port you want to configure.
- Link Type: there are 3 types of link type.
 - > Access Link: Single switch only, it allows the user to group ports by assigning the same Untagged VID. While this link type is set, the Untagged VID column field is available but the Tagged VID column field is disabled.
 - > Trunk Link: The extended application of Access Link. It allows the tagged frames go across two or more switches by assigning the tag with VID to the frames. Having set this link type, the Tagged VID column field is available but the Untagged VID column field is disabled.
 - > Hybrid Link: Both Access Link and Trunk Link are available.
- Untagged VID: Assign the untagged frame VID.
- Tagged VID: Assign the tagged frame VID.
- Click Apply to have the configuration taken effect.

AD\ANTECH				Industria	I Switch		
Open MI				ation			
🛐 Main Page			N Configura				
Bystem Port Protecot Xv VLAN VLAN		VLAN Operation Mode : [802.10 F Enable GVRP Protocol Management Vian ID : 0					
Si SNMP Bi OoS Di IOMP Si X-Ring			Δρυγ				
Si LLDP	6	802.1Q Configuration		Group Configuration			
E Becuty		0	and an and all differences of al				
See Contractor		Part Link I	ype Unitagged Vid Fai	titea aia			
S Bystem Rebpot		Induced Theread	tox The 1				
			Apply Help				
	Part.	Link Type	Untagged Vid	Tagged Vid			
	Port-01	Access Link	3	100000000			
	Port/02	Access Link	3	1000			
	Port.03	Hybrid Link	6	1024,			
	Port.04	Trunk Link	1	367,			
	Port.05	Access Link	1				
	Port.06	Hybrid Link	16	1024,			

Figure 3.36. 802.1 Q VLAIN Conliguration

Group Configuration

Edit the existing VLAN Group.

- Select the VLAN group in the table list.
- Click Edit

ADVANTECH Industrial Switch Open all Man Page Publishers Port VLAN Configuration VLAN Operation Node : 002.10 . E Protocol Enable GVRP Protocol IN VLAN Management Vian ID : 0 IN RETP IN SNMP 3 Qe8 Apply IN IGMP 🔛 X-Ring III LLOP 802.1Q Configuration Group Configuration 30 Becunty Factory Default Default Save Configuration 😰 Bystem Reboot VLAN 0 VLAN_1024___10 _1024 Edit Delote Figure 3.37: Edit Group Configuration interface

• You can Change the VLAN group name and VLAN ID.

AD\ANTECH	Industrial Switch
Open all Man Page System Port Port NAN System S	VLAN Configuration
	VLAN Operation Mode : [902.10 II]
S HOMP S HAng S LLDP	002.10 Configuration Group Configuration
Becurity Factory Default Save Configuration Solution Solution	Group Name VLAV_3 VLAN ID
	Figure 3.38: 802.1Q Group Configuration—Edit
Click Apply	

Rapid Spanning Tree

The Rapid Spanning Tree Protocol (RSTP) is an evolution of the Spanning Tree Protocol and provides for faster spanning tree convergence after a topology change. The system also supports STP and the system will auto-detect the connected device that is running STP or RSTP protocol.

RSTP - System Configuration

• The user can view spanning tree information of the Root Bridge.

- The user can modify RSTP state. After modification, click Apply
 - > **RSTP mode:** The user must enable the RSTP function first before configuring the related parameters.
 - Priority (0-61440): The switch with the lowest value has the highest priority and is selected as the root. If the value is changed, the user must reboot the switch. The value must be a multiple of 4096 according to the protocol standard rule.
 - Max Age (6-40): The number of seconds a switch waits without receiving Spanning-tree Protocol configuration messages before attempting a reconfiguration. Enter a value between 6 through 40.
 - Hello Time (1-10): The time that controls the switch to send out the BPDU packet to check RSTP current status. Enter a value between 1 through 10.
 - Forward Delay Time (4-30): The number of seconds a port waits before changing from its Rapid Spanning-Tree Protocol learning and listening states to the forwarding state. Enter a value between 4 through 30.

Note

Follow the rule to configure the MAX Age, Hello Time, and Forward Delay Time.

2 x (Forward Delay Time value -1) > = Max Age value >= 2 x (Hello Time value +1)



Figure 3.39: RSTP System Configuration interface

RSTP—Port Configuration

Here you can configure the path cost and priority of each port.

- Select the port in the port column field.
- **Path Cost:** The cost of the path to the other bridge from this transmitting bridge at the specified port. Enter a number 1 through 200,000,000.
- **Priority:** Decide which port should be blocked by priority in LAN. Enter a number 0 through 240 (the port of the highest value will be blocked). The value of priority must be the multiple of 16.

- Admin P2P: Some of the rapid state transactions that are possible within RSTP are dependent upon whether the port concerned can only be connected to exactly one other bridge (i.e. it is served by a point-to-point LAN segment), or can be connected to two or more bridges (i.e. it is served by a shared medium LAN segment). This function allows the P2P status of the link to be manipulated administratively. True is P2P enabling. False is P2P disabling.
- Admin Edge: The port directly connected to end stations won't create bridging loop in the network. To configure the port as an edge port, set the port to "True" status.
- Admin Non Stp: The port includes the STP mathematic calculation. True is not including STP mathematic calculation. False is including the STP mathematic calculation.
- Click Apply

						In	dustrial	S	
R	STP	- P	or	tC	onfi	gura	tion		
System Configuration Port Configuration									
Port (1	Path Co 200000	ost 0000) (Priorit (0-240	V Ad	min P2P	Admin Edg	e Admin Non Stp		
Port.01 + Port.03 Port.04 Port.05 +	20000	x	128	A	uto 💌	true 💌	false 💌		
prior	ity must	t be a n	Ap	ply Dor	6 Heb				
Port	Path Cest	Part	Oper	Oper	Stp	State	Role		
Port.01	200000	128	True	True	False	Disabled	Disabled		
Port.02	200000	128	True	True	False	Disabled	Disabled		
Port.03	200000	128	True	True	False	Disabled	Disabled		
Port.04	200000	120	True	True	False	Disabled	Disabled		
Port.05	200000	128	True	True	False	Forwarding	Designated		
	Port 01 Port 01 Port 03 Port 04 Port 05 Port 05 Port 05 Port 04 Port 05 Port 01 Port 05 Port 05 Port 01 Port 05 Port 0	Port Origonal Port Origonal Port 01 • Port 03 • Port 03 • Port 03 • Port 03 • Port 01 200000 Port 02 200000	RSTP - P System Configuration Port 01 Path Cost (1-2000000000) Port 01 Path Cost (1-2000000000) Port 01 Path Cost (1-200000000) Port 02 Port 02 Port 02 Port 01 Path Pert Principly Port 02 200000 128 Port 02 200000 128 Port 03 200000 128 Port 03 200000 128 Port 03 200000 128 Port 05 200000 128	RSTP - Port System Configuration Port 01 Path Cost Priorit (1-2000000000) (0-240 Port 01 Path Cost Priorit (1-200000000) (0-240 Port 02 Port 03 Port 04 Port 05 Port 05 Port 01 Port 02 Port 01 Port 01 Port 01 Port 02 Port 01 Port 02 Port 01 Port 02 Port 02 Port 01 Port 02 Port	RSTP - Port C System Configuration Port Peth Cost Priority Ad Port 01 Port 01 Port 02 Port 03 Port 04 Port 03 Port 03 Port 04 Port 03 Port 04 Port 03 Port 04 Port 03 Port 04 Port 03 Port 04 Port 04 P	Port Configuration Port Orifiguration Port 01 Port 02 Priority (0-240) Admin P2P Port 03 200000 128 Auto * Port 04 200000 128 Auto * Port 05 200000 128 Auto * Port 05 200000 128 Auto * Port 05 200000 128 Tue * Port 05 Port 05 Port 05 Port 05 Port 05 200000 128 Tue * Port 05 Port 05 Port 05 Port 05 Port 05 200000 128 Tue * Port 05	Port Configuration System Configuration Port Cost Port Cost <td>Intervention System Configuration Port Configuration <th cols<="" td=""></th></td>	Intervention System Configuration Port Configuration <th cols<="" td=""></th>	

SNMP Configuration

Simple Network Management Protocol (SNMP) is the protocol developed to manage nodes (servers, workstations, routers, switches and hubs etc.) on an IP network. SNMP enables network administrators to manage network performance, find and solve network problems, and plan for network growth. Network management systems learn of problems by receiving traps or change notices from network devices implementing SNMP.

System Configuration

Community Strings

Here you can define the new community string set and remove the unwanted community string.

- String: Fill the name string.
- RO: Read only. Enables requests accompanied by this community string to display MIB-object information.
- RW: Read write. Enables requests accompanied by this community string to display MIB-object information and to set MIB objects.
- Click Add

• To remove the community string, select the community string that you have defined and click Remove . You cannot edit the name of the default community string set.

Agent Mode

Select the SNMP version that you want to use and then click Change to switch to the selected SNMP version mode. The default value is 'SNMP v1/v2c only'.

AD\ANTECH	Industrial Switch
Open all S Main Page	SNMP - System Configuration
System Pert Pert Pert Pert NUAN RSTP DoS NMP NAMP NAMP NAMP NAMP NAMP NAMP NAMP NAMP NAMP Security Security	System Configuration Trap Configuration SNMPv3 Configuration
	Agent Mode Current Mode: STUMP v1/v2c only STUMP v1/v2c only StUMP v1/v2c only StUMP v1/v2c/v3 Change
	Holp

Figure 3.41: SNMP System Configuration interface

Trap Configuration

A trap manager is a management station that receives the trap messages generated by the switch. If no trap manager is defined, no traps will be issued. Create a trap manager by entering the IP address of the station and a community string. To define a management station as a trap manager, assign an IP address, enter the SNMP community strings, and select the SNMP trap version.

- IP Address: Enter the IP address of the trap manager.
- Community: Enter the community string.
- Trap Version: Select the SNMP trap version type—v1 or v2c.
- Click Add
- To remove the community string, select the community string listed in the current managers field and click Remove.
| AD\ANTECH | |
|-------------------------------------|--|
| | Industrial Swit |
| Open all | SNMP - Trap Configuration |
| E gistem | System Configuration Trop Configuration SNMPv3 Configuration |
| Protocol | Trep Menegers |
| III FESTP | Current Managers : New Manager : Add |
| I GoB | 192.168.1.21: TracHost1, v1
192.168.1.22: TracHost2, v2 |
| B X-Ring
D Security | Community: TrapHost3
Trap version: @ v1 C v2c |
| Save Configuration
System Reboot | Help |

Figure 3.42: Trap Configuration interface

SNMPV3 Configuration

Configure the SNMP V3 function.

Context Table

Configure SNMP v3 context table. Assign the context name of context table. Click Add to add context

name. Click Remove to remove unwanted context name.

User Profile

Configure SNMP v3 user table.

- User ID: Set up the user name.
- Authentication Password: Set up the authentication password.
- Privacy Password: Set up the private password.
- Click Add to add context name.
- Click Remove to remove unwanted context name.



Group Table

Configure SNMP v3 group table.

- Security Name (User ID): Assign the user name that you have set up in user table.
- Group Name: Set up the group name.
- Click Add to add context name.
- Click Remove to remove the unwanted context name.

Access Table

Configure SNMP v3 access table.

- Context Prefix: Set up the context name.
- Group Name: Set up the group.
- Security Level: Set up the access level.
- Context Match Rule: Select the context match rule.
- Read View Name: Set up the read view.
- Write View Name: Set up the write view.
- Notify View Name: Set up the notify view.
- Click Add to add context name.
- Click Remove to remove unwanted context name.

MIBview Table

Configure MIB view table.

- ViewName: Set up the name.
- Sub-Oid Tree: Fill the Sub OID.
- Type: Select the type—excluded or included.
- Click Add to add context name.
- Click Remove to remove unwanted context name.

QoS Configuration

Here you can configure Qos policy and priority setting, per port priority setting, COS and TOS setting.

QoS Policy and Priority Type

- Qos Policy: Select the QoS policy rule.
 - Use an 8,4,2,1 weighted fair queuing scheme: The switch will follow 8:4:2:1 rate to process priority queue from High to lowest queue. For example, while the system processing, 1 frame of the lowest queue, 2 frames of the low queue, 4 frames of the middle queue, and 8 frames of the high queue will be processed at the same time in accordance with the 8,4,2,1 policy rule.
 - Use a strict priority scheme: Always the higher queue will be processed first, except the higher queue is empty.
 - Priority Type: There are 5 priority type selections available—Port-based, TOS only, COS only, TOS first, and COS first. Disable means no priority type is selected.
- Click Apply to have the configuration taken effect.

AD\ANTECH Industrial Switch QoS Configuration Open at III Main Plage 🕀 🔄 Bystem Qos Policy: III 🛄 Port E Protocol IN VLAN ¹⁹ Use an 0,4,2,1 weighted fair queuing scheme ASTP C use a strict priority scheme I SNMP B 905 Apply Help IN IOMP 🐻 %-fing I LLDP Port-based Priority: H Security Port.03 Port.04 Port.05 Part.06 Port.01 Port.02 Mr Factory Default Save Configuration Lowest * Lowest * Lowest * Lowest * Lowest * Lowest * III System Reboot Apply Help COS: Priority 2 4 0 1 3 5 6 7 Lowest * Apply Help TOS: 2 3 Priority 0 1 4 5 6 Lowest . Priority 8 10 11 12 9 13 14 15 Lowest . Priority 16 17 18 19 20 21 22 23 Lowest . 25 26 27 29 Priority 24 28 30 31 Lowest * Priority 32 33 34 35 36 37 38 39 Lawest . Lowest . **Priority** 40 41 42 43 44 45 46 47 Lowest . 51 50 48 49 Priority 52 53 54 55 Lowest * 56 57 59 Priority 58 60 61 62 63 Lowest . Apply Help

Figure 3.44: QoS Configuration interface

Port Base Priority

Configure the priority level for each port. With the drop-down selection item of **Priority Type** above being selected as Port-based, this control item will then be available to set the queuing policy for each port.

- Port x: Each port has 4 priority levels—High, Middle, Low, and Lowest—to be chosen.
- Click Apply to have the configuration taken effect.

COS Configuration

Set up the COS priority level. With the drop-down selection item of **Priority Type** above being selected as COS only/COS first, this control item will then be available to set the queuing policy for each port.

- COS priority: Set up the COS priority level 0~7—High, Middle, Low, Lowest.
- Click Apply

TOS Configuration

Set up the TOS priority. With the drop-down selection item of **Priority Type** above being selected as TOS only/TOS first, this control item will then be available to set the queuing policy for each port.

- **TOS priority:** The system provides 0~63 TOS priority level. Each level has 4 types of priority—High, Middle, Low, and Lowest. The default value is 'Lowest' priority for each level. When the IP packet is received, the system will check the TOS level value in the IP packet that has received. For example, the user sets the TOS level 25 as high, the system will check the TOS value of the received IP packet. If the TOS value of received IP packet is 25 (priority = high), and then the packet priority will have the highest priority.
- Click Apply to have the configuration taken effect.

IGMP Configuration

The Internet Group Management Protocol (IGMP) is an internal protocol of the Internet Protocol (IP) suite. IP manages multicast traffic by using switches, routers, and hosts that support IGMP. Enabling IGMP allows the ports to detect IGMP queries, report packets, and manage IP multicast traffic through the switch. IGMP have three fundamental types of message shown as follows:

Table 3.19: IGMP types		
Message	Description	
Query	A message sent from the querier (IGMP router or switch) asking for a response from each host belonging to the multicast group.	
Report	A message sent by a host to the querier to indicate that the host wants to be or is a member of a given group indicated in the report message.	
Leave Group	A message sent by a host to the querier to indicate that the host has quit being a member of a specific multicast group.	

The switch supports IP multicast. You can enable IGMP protocol via setting the IGMP Configuration page to see the IGMP snooping information. IP multicast addresses are in the range of 224.0.0.0 through 239.255.255.255.

- IGMP Protocol: Enable or disable the IGMP protocol.
- **IGMP Query:** Select the IGMP query function as Enable or Auto to set the switch as a querier for IGMP version 2 multicast networks.
- Click Apply

AD\ANTECH				
			Industria	I Switch
Open all	IGM	IP Configu	ration	
🕂 🔄 Byslem	IP Address	VLAN ID	Member Port	
Port Protocol VLAN RETP SNMP OCS VCAN Cos Cos	239.255.255.255.250	l	****5*	
ELLOP F Security		IGMP Secoping: Enable		
1 Factory Default		IGMP Query: Auto	*	
Si Save Configuration Si System Retroot		Apply Help		

Figure 3.45: IGMP Configuration interface

X-Ring

X-Ring provides a faster redundant recovery than Spanning Tree topology. The action is similar to STP or RSTP, but the algorithms between them are not the same.

In the X-Ring topology, every switch should be enabled with X-Ring function and two ports should be assigned as the member ports in the ring. Only one switch in the X-Ring group would be set as the master switch that one of its two member ports would be blocked, called backup port, and another port is called working port. Other switches in the X-Ring group are called working switches and their two member ports are called working ports. When the failure of network connection occurs, the backup port of the master switch (Ring Master) will automatically become a working port to recover from the failure.

The switch supports the function and interface for setting the switch as the ring master or not. The ring master can negotiate and place command to other switches in the X-Ring group. If there are 2 or more switches in master mode, the software will select the switch with lowest MAC address number as the ring master. The X-Ring master ring mode can be enabled by setting the X-Ring configuration interface. Also, the user can identify whether the switch is the ring master by checking the R.M. LED indicator on the panel of the switch.

The system also supports the **Couple Ring** that can connect 2 or more X-Ring group for the redundant backup function; **Dual Homing** function that can prevent connection lose between X-Ring group and upper level/core switch. Apart from the advantages, **Central Ring** can handle up to 4 rings in the system and has the ability to recover from failure within 10 milliseconds.

- Enable X-Ring: To enable the X-Ring function, tick the checkbox beside the Enable Ring string label. If this checkbox is not ticked, all the ring functions are unavailable.
 - > Enable Ring Master: Tick the checkbox to enable this switch to be the ring master.
 - Ist & 2nd Ring Ports: Pull down the selection menu to assign the ports as the member ports. 1_{st} Ring Port is the working port and 2_{nd} Ring Port is the backup port. When 1_{st} Ring Port fails, the system will automatically upgrade the 2_{nd} Ring Port to be the working port.
- Enable Couple Ring: To enable the coupe ring function, tick the checkbox beside the Enable Couple Ring string label.
 - > **Couple port**: Assign the member port which is connected to the other ring group.

Control port: When the Enable Couple Ring checkbox is ticked, you have to assign the control port to form a couple-ring group between the two X-rings.

- Enable Dual Homing: Set up one of the ports on the switch to be the Dual Homing port. For a switch, there is only one Dual Homing port. Dual Homing function only works when the X-Ring function enabled.
- Enable Dual Ring: When this check box is ticked and click Apply, the 'Enable Ring Master' check box will then also be enabled by the system which means this equipment is assigned as Ring Master. The Dual Ring differs from the Couple Ring in that it only needs a unit to form a redundant linking system of two rings.
- And then, click Apply to apply the configuration.

ADVANTECH

Industrial Switch

Open all	X-Ring Configuration		
III 🦲 System III 🛁 Port	F Enable Ring		
I HTODOGIC	1st Ring Port	Port.01 .	FORWARDING
IN RSTP	2nd Ring Port	Port.02 ·	LINKDOWN
OR BAMP	F Enable Couple Ring		
G CoS G SOMP G X-Ring G LLDP	Couple Port	Port.03 ·	LINKDOWN
	Control Port	Port.04 *	LINKDOWN
	F Enable Dual Homing		
	Homing Port	Port.05	LINKDOWN
Factory Default	🖓 Enable Dual Ring		
Save Configuration	1st Ring Port	Port.01 ·	FORWARDING
🔝 System Reboot	2nd Ring Port	Port.01 ·	FORWARDING

Figure 3.46: X-ring interface

Note

When the X-Ring function enable, user must disable the RSTP. The X-Ring function and RSTP function cannot exist at the same time. Remember to execute the "Save Configuration" action, otherwise the new configuration will lose when switch power off.

LLDP Configuration

LLDP (Link Layer Discovery Protocol) function allows the switch to advertise its information to other nodes on the network and store the information it discovers.

- **LLDP Protocol:** Disable or enable LLDP function.
- LLDP Interval: Set the interval of learning the information time in second.
- Click Apply

AD\ANTECH	
	Industrial Switch
Open all Main Page Bystem Port Pritticol VLAN B RSTP S SNMP	LLDP Protocol: Disable : LLDP Interval: 30 sec
Ord Ord Order Sching	



3.2.4 Security

In this section, you can configure 802.1x and MAC address table.

802.1X/Radius Configuration

802.1x is an IEEE authentication specification which prevents the client from connecting to a wireless access point or wired switch until it provides authority, like the user name and password that are verified by an authentication server (such as RADIUS server).

802.1X/Radius - System Configuration

After enabling the IEEE 802.1X function, you can configure the parameters of this function.

- IEEE 802.1x Protocol: Enable or disable 802.1x protocol.
- Radius Server IP: Assign the RADIUS Server IP address.
- Server Port: Set the UDP destination port for authentication requests to the specified RADIUS Server.
- Accounting Port: Set the UDP destination port for accounting requests to the specified RADIUS Server.
- Shared Key: Set an encryption key for using during authentication sessions with the specified RADIUS server. This key must match the encryption key used on the RADIUS Server.
- NAS, Identifier: Set the identifier for the RADIUS client.
- Click Apply

			Industrial Sw
per al	802.1x/Radi	us - System C	onfiguration
System	System Configuration	Port Configuration	Mise Configuration
🛄 Protocol 🖄 Security	602.1× P	rotocel Enable 💌	
(% 602.1:xRadius (% MAC Address Table)	Radius Se Server	Port 192 168.1.235	
Factory Default Save Configuration	Accounti	ng Port 1813	
System Reboat	Shared	12345678	
	NAS, Ide	ntifier NAS_L2_SWITCH	

Figure 3.48: 802.1x/Radius System Configuration Interfac

802.1x/Radius—Port Configuration

You can configure the 802.1x authentication state for each port. The state provides Disable, Accept, Reject, and Authorize.

- **Reject:** The specified port is required to be held in the unauthorized state.
- Accept: The specified port is required to be held in the Authorized state.
- **Authorized:** The specified port is set to the Authorized or Unauthorized state in accordance with the outcome of an authentication exchange between the Supplicant and the authentication server.
- Disable: When disabled, the specified port works without complying with 802.1x protocol.
- Click Apply

AD\ANTECH				
			Industria	Switch
Open all	802.1x/Rad	lius - Port (Configuration	
E System	Systam Configuration	Port Configuration	Mise Configuration	
Port Protocol Protocol Security Security	Por Por Por Por	Accity Accity Accity Accity Accity Helping	State	
		Port Autoonzabl	State	
	ρ	ort.01	Disable	
	-	ort.02	Disable	
	P	ort.03	Disablo	
	P	ort.04	Disable	
		ort.05	Disable	
		017,05	DISADIO	

Figure 3.49: 802.1x/Radius - Port Setting interface

802.1X/Radius—Misc Configuration

- Quiet Period: Set the period which the port doesn't try to acquire a supplicant.
- TX Period: Set the period the port waits for retransmit next EAPOL PDU during an authentication session.
- Supplicant Timeout: Set the period of time the switch waits for a supplicant response to an EAP request.
- Server Timeout: Set the period of time the switch waits for a server response to an authentication request.
- Max Requests: Set the number of authentication that must time-out before authentication fails and the authentication session ends.
- Reauth period: Set the period of time which clients connected must be re-authenticated.
- Click Apply

			Industria
n all	802.1x/Rad	lius - Misc C	configuration
) Byotem J Port	System Configuration	Port Configuration	Misc Configuration
Protocol Recurty		Quiet Period	60
 002.1xRadus 		Tx Period	30
MAC Address Table		Supplicant Timeout	30
Save Configuration		Server Timeout	30
Bystem Reboot		Max Requests	2
		Reauth Period	3600

Figure 3.50: 802.1x/Radius - Misc Configuration Interface

MAC Address Table

Use the MAC address table to ensure the port security.

You can add a static MAC address; it remains in the switch's address table, regardless of whether the device is physically connected to the switch. This saves the switch from having to re-learn a device's MAC address when the disconnected or powered-off device is active on the network again. You can add / modify / delete a static MAC address.

MAC Address Table—Static MAC Address

You can add static MAC address in the switch MAC table here.

- MAC Address: Enter the MAC address of the port that should permanently forward traffic, regardless of the device network activity.
- Port No.: Pull down the selection menu to select the port number.
- Click Add
- If you want to delete the MAC address from filtering table, select the MAC address and click Delete

ADIANTECH	
Open all Man Page Support Port Protocol Becunty MAC Address Table Factory Default	Industrial Switch MAC Address Table - Static MAC Addresses Static MAC Addresses MAC Filtering All Mac Addresses Multicast Filtering Multicast Filtering
 Save Configuration Bystem Reboot 	MAC Address Part No. Port.01 - Add Delete Help

Figure 3.51: Static MAC Addresses interface

MAC Address Table—MAC Filtering

By filtering MAC address, the switch can easily filter the pre-configured MAC address and reduce the unsafety. You can add and delete filtering MAC address.

AD\ANTECH	Industrial Sudtak
Open all	MAC Address Table - MAC Filtering
Open all Main Page Bystem Pritical Becuity B3 892 txRadius MAC Address Table Factory Definit Base Configuration Bystem Reboot	Static MAC Addresses MAC Filtering All Mac Addresses Multicast Filtering DDCCEEFFAABS MAC Address 02ABCSE455F0 Add Delete Heb
	Figure 3.52: MAC Filtering interface

- MAC Address: Enter the MAC address that you want to filter.
- Click Add
- If you want to delete the MAC address from filtering table, select the MAC address and click Delete

MAC Address Table—All MAC Addresses

You can view the port that connected device's MAC address and the related devices' MAC address.

- Select the port.
- The selected port of static & dynamic MAC address information will be displayed in here.
- Click Clear MAC Table to clear the current port static MAC address information on screen.

ADVANTECH	Industrial Switc
Open all	MAC Address Table - All Mac Addresses
E Bystem	Static MAC Addresses MAC Filtering All Mac Addresses Nutlicast Filtering
Port Protacol Security S) 892 1xRadius W/ MAC Address Table Factory Default Base Curriguration S System Reboot	Pert Net Port.01
	Dynamic Address Count:0 Static Address Count: 1
	Clear MAC Table

Figure 3.53: All MAC Address interface

MAC Address Table—Multicast Filtering

Multicasts are similar to broadcasts, they are sent to all end stations on a LAN or VLAN. Multicast filtering is the system by which end stations only receive multicast traffic if they register to join specific multicast groups. With multicast filtering, network devices only forward multicast traffic to the ports that are connected to registered end stations.

- IP Address: Assign a multicast group IP address in the range of 224.0.0.0 ~ 239.255.255.255.
- Member Ports: Tick the check box beside the port number to include them as the member ports in the specific multicast group IP address.
- Click Clear MAC Table to clear the current port static MAC address information on screen.

AD\ANTECH Industrial Switch MAC Address Table - Multicast Filtering Open all Main Page B System Static MAC Addresses MAC Filtering All Mac Addresses Multicast Filtering Fini Port 1*2***** 224.000.000.100 B Carl Security 224.000.001.100 * 3* 4*** B02.1xRadius MAC Address Table E Factory Default I Save Configuration (i) System Reboot **IP Address** 224.0.2.100 E Port.01 E Port.02 E Port.03 E Port.04 nber Ports Port.05 Part.06 Add Delete Help Figure 3.54: All MAC Address interface

Reset switch to default configuration. Click Reset to reset all configurations to the default value.

ADVANTECH	
	Industrial Switch
Open all	Factory Default
Fill Bystem Fill Port Filt Protocol	R Keep current IP address setting? R Keep current username & password?
Becuty Factory Default See Contiguration	Reset Heb
Bystem Reboot	

Figure 3.55: Factory Default interface

Save Configuration

Factory Default

Save all configurations that you have made in the system. To ensure the all configuration will be saved, click Save to save the all configuration to the flash memory.

ADVANTECH	
	Industrial Switch
Open all	Save Configuration
Warn Page Jystam Jystam Port Protocol Security Factory Default Bare Configuration	Save Help
🚡 Bystem Reboot	Figure 3.56: Save Configuration interface
System Reboot	
Reboot the switch in	n software reset. Click Reboot to reboot the system.
AD\ANTECH	
	Industrial Switch
Open all	System Reboot
R Mam Page R J Bystem	Please click (Reboot) button to restart switch device.
Port Protocol	Rebot
Factory Default Save Configuration Default Default	

Figure 3.57: System Reboot interface



Troubleshooting

Chapter 4 Troubleshooting

Verify that is using the right power cord/adapter (+12 \sim 48V_{DC}), please don't use the power adaptor with DC output voltage higher than 48V, or it might burn this converter down.

Select the proper UTP cable to construct user network. Please check that is using the right cable. Use Unshielded Twisted-Pair (UTP) or Shielded Twisted-Pair (STP) cable for RJ-45 connections: 100 Category 3, 4 or 5 cable for 10 Mbps connections or 100 Category 5 cable for 100 Mbps connections. Also, be sure that the length of any twisted-pair connection does not exceed 100 meters (328 feet).

Diagnosing LED Indicators

To assist in identifying problems, the switch can be easily monitored through panel indicators, which describe common problems the user may encounter and where the user can find possible solutions.

If the power indicator does not light up when the power cord is plugged in, the user may have a problem with power cord. Then check for loose power connections, power losses or surges at power outlet. If the user still cannot resolve the problem, contact the local dealer for assistance.

If the Industrial switch LED indicators are normal and the connected cables are correct but the packets still cannot transmit, please check your system's Ethernet devices configurations or status.

APPENDIX

Pin Assignment & Wiring

Appendix A Pin Assignment & Wiring

It is suggested to adopt ELA/TIA as the wiring of the RJ-45.



Figure A.1: RJ-45 Pin Assignment



- 6. Orange
- 7. White, Brown
- 8. Brown

Figure A.3: EIA/TIA-568A



DB 9-pin Female Figure A.4: DB 9-pin female connector

DB9 Connector	RJ-45 Connector
NC	1 Orange/White
2	2 Orange
3	3 Green/White
NC	4 Blue
5	5 Blue/White
NC	6 Green
NC	7 Brown/White
NC	8 Brown